

Lanner

Embedded Computing

Embedded Computing Platforms for Industrial and Commercial Applications

LEC-2137 User Manual

Version: 1.1

Date of Release: 2018-08-27

Icon Descriptions

The icons are used in the manual to serve as an indication of interest topics or important messages. Below is a description of these icons:



Note: This check mark indicates that there is a note of interest and is something that you should pay special attention to while using the product.



Warning: This exclamation point indicates that there is a caution or warning and it is something that could damage your property or product.

Online Resources

The listed websites are links to the on-line product information and technical support.

Resources	URL
Lanner	http://www.lannerinc.com
Product Resource	http://www.lannerinc.com/download-center
RMA	http://eRMA.lannerinc.com

Copyright and Trademarks

This document is copyrighted © 2018. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, nor for any infringements upon the rights of third parties that may result from such use.

Acknowledgement

Intel®, Intel® Atom® and Intel® Celeron® are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

Compliances and Certification

CE

This product has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

FCC Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. The operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

EMC Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. The operation of this equipment in a residential area is likely to cause harmful interference in which case users will be required to correct the interference at their own expense.

Safety Guidelines

Follow these guidelines to ensure general safety:

- ▶ Keep the chassis area clear and dust-free during and after installation.
- ▶ Do not wear loose clothing or jewelry that could get caught in the chassis. Fasten your tie or scarf and roll up your sleeves.
- ▶ Wear safety glasses if you are working under any conditions that might be hazardous to your eyes.
- ▶ Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- ▶ Disconnect all power by turning off the power and unplugging the power cord before installing or removing a chassis or working near power supplies
- ▶ Do not work alone if potentially hazardous conditions exist.
- ▶ Never assume that power is disconnected from a circuit; always check the circuit.

Lithium Battery Caution:

- ▶ Risk of Explosion if Battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- ▶ Installation only by a trained electrician or only by an electrically trained person who knows all English Installation and Device Specifications which are to be applied.
- ▶ Do not carry the handle of power supplies when moving to another place.
- ▶ The machine can only be used in a fixed location such as labs or computer facilities.

Operating Safety

- ▶ Electrical equipment generates heat. Ambient air temperature may not be adequate to cool equipment to acceptable operating temperatures without adequate circulation. Be sure that the room in which you choose to operate your system has adequate air circulation.
- ▶ Ensure that the chassis cover is secure. The chassis design allows cooling air to circulate effectively. An open chassis permits air leaks, which may interrupt and redirect the flow of cooling air from internal components.
- ▶ Electrostatic discharge (ESD) can damage equipment and impair electrical circuitry. ESD damage occurs when electronic components are improperly handled and can result in complete or intermittent failures. Be sure to follow ESD-prevention procedures when removing and replacing components to avoid these problems.
- ▶ Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. If no wrist strap is available, ground yourself by touching the metal part of the chassis.
- ▶ Periodically check the resistance value of the antistatic strap, which should be between 1 and 10 megohms (Mohms).

Mounting Installation Precaution

Environment:

- ▶ Do not install and/or operate this unit in any place that flammable objects are stored or used in.
- ▶ If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T_{ma}) specified by the manufacturer.
- ▶ Installation of the equipment (especially in a rack) should consider the ventilation of the system's intake (for taking chilled air) and exhaust (for emitting hot air) openings so that the amount of air flow required for safe operation of the equipment is not compromised.
- ▶ To avoid a hazardous load condition, be sure the mechanical loading is even when mounting.
- ▶ Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on over-current protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

- ▶ Reliable earthing should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).
- ▶ Lanner Electronics Inc. shall not be held liable for any losses resulting from insufficient strength for supporting the unit or use of inappropriate installation components.

Installation & Operation:

- ▶ The installation of this product must be performed by trained specialists; otherwise, a non-specialist might create the risk of the system's falling to the ground or other damages.
- ▶ Lanner Electronics Inc. shall not be held liable for any losses resulting from insufficient strength for supporting the system or use of inappropriate installation components.

Consignes de sécurité

Suivez ces consignes pour assurer la sécurité générale :

- ▶ Laissez la zone du châssis propre et sans poussière pendant et après l'installation.
- ▶ Ne portez pas de vêtements amples ou de bijoux qui pourraient être pris dans le châssis. Attachez votre cravate ou écharpe et remontez vos manches.
- ▶ Portez des lunettes de sécurité pour protéger vos yeux.
- ▶ N'effectuez aucune action qui pourrait créer un danger pour d'autres ou rendre l'équipement dangereux.
- ▶ Coupez complètement l'alimentation en éteignant l'alimentation et en débranchant le cordon d'alimentation avant d'installer ou de retirer un châssis ou de travailler à proximité de sources d'alimentation.
- ▶ Ne travaillez pas seul si des conditions dangereuses sont présentes.
- ▶ Ne considérez jamais que l'alimentation est coupée d'un circuit, vérifiez toujours le circuit. Cet appareil génère, utilise et émet une énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions des fournisseurs de composants sans fil, il risque de provoquer des interférences dans les communications radio.

Avertissement concernant la pile au lithium

- ▶ Risque d'explosion si la pile est remplacée par une autre d'un mauvais type.
- ▶ Jetez les piles usagées conformément aux instructions.
- ▶ L'installation doit être effectuée par un électricien formé ou une personne formée à l'électricité connaissant toutes les spécifications d'installation et d'appareil du produit.
- ▶ Ne transportez pas l'unité en la tenant par le câble d'alimentation lorsque vous déplacez l'appareil.
- ▶ La machine ne peut être utilisée qu'à un lieu fixe comme en laboratoire, salle d'ordinateurs ou salle de classe.

Sécurité de fonctionnement

L'équipement électrique génère de la chaleur. La température ambiante peut ne pas être adéquate pour refroidir l'équipement à une température de fonctionnement acceptable sans circulation adaptée. Vérifiez que votre site propose une circulation d'air adéquate.

- ▶ Vérifiez que le couvercle du châssis est bien fixé. La conception du châssis permet à l'air de refroidissement de bien circuler. Un châssis ouvert laisse l'air s'échapper, ce qui peut interrompre et rediriger le flux d'air frais destiné aux composants internes.
- ▶ Les décharges électrostatiques (ESD) peuvent endommager l'équipement et gêner les circuits électriques. Des dégâts d'ESD surviennent lorsque des composants électroniques sont mal manipulés et peuvent causer des pannes totales ou intermittentes. Suivez les procédures de prévention d'ESD lors du retrait et du remplacement de composants.
- ▶ Portez un bracelet anti-ESD et veillez à ce qu'il soit bien au contact de la peau. Si aucun bracelet n'est disponible, reliez votre corps à la terre en touchant la partie métallique du châssis.
- ▶ Vérifiez régulièrement la valeur de résistance du bracelet antistatique, qui doit être comprise entre 1 et 10 mégohms (Mohms).

Consignes de sécurité électrique

- ▶ Avant d'allumer l'appareil, reliez le câble de mise à la terre de l'équipement à la terre.
- ▶ Une bonne mise à la terre (connexion à la terre) est très importante pour protéger l'équipement contre les effets néfastes du bruit externe et réduire les risques d'électrocution en cas de foudre.
- ▶ Pour désinstaller l'équipement, débranchez le câble de mise à la terre après avoir éteint l'appareil.
- ▶ Un câble de mise à la terre est requis et la zone reliant les sections du conducteur doit faire plus de 4 mm² ou 10 AWG.

Revision History

Version	Date	Descriptions
1.0	2018/04/03	1 st Official Release
1.1	2018/08/27	Modified R6 Reset Button definition

Table of Contents

Chapter 1: Product Overview	10
Package Content.....	10
Ordering Information	11
System Specifications	11
Front Panel	13
Rear Panel.....	14
Chapter 2: Motherboard Information	15
Block Diagram.....	15
Motherboard Layout	18
Internal Jumper & Connectors	19
Chapter 3: Hardware Setup.....	22
Opening the Chassis	22
Remove the PoE Power Board	23
Installing the System Memory.....	24
Installing the mSATA.....	25
Installing 3G Supported Module	26
Installing the Disk Drive.....	28
Chapter 4: BIOS Setup	29
Enter BIOS Setup	29
Main.....	30
Advanced Setup.....	31
Chipset	48
Security.....	54

Boot Menu.....	57
Save and Exit Menu	58
Appendix A: LED Indicator Explanations	59
Appendix B: Programming Watchdog Timer.....	60
Appendix C: Setting up Console Redirections	61
Appendix D: Installing Intel® LAN Controller Driver for Linux	62
Appendix E: Terms and Conditions	63
Warranty Policy	63
RMA Service.....	63
RMA Service Request Form	64


CHAPTER 1: PRODUCT OVERVIEW

The LEC-2137 is a fanless and robust embedded box PC system utilizing the Intel Apollo Lake CPU with improved graphical and media performance, including support USB 3.0, Low-powered DDR3/L and VGA/HDMI display. The system is ideal for efficient imaging workflows, digital signage with secure content delivery, visually appealing interactive clients (interactive kiosks, intelligent vending, ATM and point-of-sale (POS) terminals) and industrial control systems.

Package Content

Your package contains the following items:

- ▶ 1x LEC-2137 Embedded Compact PC
- ▶ 1x pack of Rubber Pads
- ▶ 1x Pack of Screws
- ▶ 1x Power Adapter
- ▶ 1x SATA Cable



Note: If you should find any components missing or damaged, please contact your dealer immediately for assistance.

Ordering Information


SKU No.	
LEC-2137A	Intel E3950 4 Cores+6x GbE
LEC-2137B	Intel E3950 4 Cores+2x GbE+ 4x PoE
LEC-2137C	Intel N3350 2 Cores+6x GbE
LEC-2137D	Intel N3350 2 Cores+2x GbE+ 4x PoE

System Specifications

Processor System	CPU	Intel® Atom™ x7-E3950 or Celeron® N3350
	Frequency	Base frequency 1.6 GHz/1.1 GHz Burst frequency 2.0 GHz/2.4 GHz
	Core Number	4C/2C
	Chipset	SOC
Fanless		Yes
Memory	Technology	DDR3L 1333/1600/1866 MHz
	Max. Capacity	8GB
	Socket	1x 204-pin SODIMM
Graphic	Controller	Intel® HD Graphics
	VGA	1x VGA, 1600 x 1200
	DVI	-
	HDMI	1x HDMI, 3840 x 2160@30Hz
Audio	Codec	-
	Interface	-
Ethernet	Controller	Intel® i210
	Speed	10/100/1000 Mbps
	Interface	6x RJ45 (Including 4x PoE Option)
Storage	Type	SATA III
	Installation	1x mSATA Socket (Half Size)
	Type	SATA III
	Installation	1x 2.5" HDD/SSD Drive Bay
I/O	Serial Port	1x RS-232/422/485, DB9 Male
	Digital I/O	-
	USB 2.0	2x Type A
	USB 3.0	2x Type A
	Power-On/ Reset Button	1x Power On/Off, 1x Reset
	Remote	-
	LED	Power/HDD/3G
Antenna Hole	2x SMA Antenna Hole	
Expansion Interface	Mini-PCIe	1x Full-sized Socket with SIM Card Reader, Socket with USB 2.0 signals (only USB 2.0)
Watchdog Timer		Watchdog Timer 1~255 Level Time Interval System Reset, Software Programmable
Power	Power Type	ATX
	Power Supply Voltage	+12VDC ~ +30VDC
	Connector	2-pin Terminal Block


Power	Power Consumption (Idle)	10.266W
	Power Consumption (Full Load)	21.424W
	Power consumption (with all PoE ports supplying power to 4x IP cameras)	54.405W
	Power Adaptor	AC to DC, AC 90 to 240 VAC Input DC 24VDC/2.5A 60W /120W
Environment	Operating Temperature	LEC-2137A/LEC-2137B: -20°C to 55°C LEC-2137C/LEC-2137D: 0°C to 50°C
	Storage Temperature	-20°C to 70°C
	Relative Humidity	5% to 95%, non-condensing
	Vibration	IEC 60068-2-64, 0.5Grms, Random 5 to 500Hz, 40 Mins/Axis
Mechanical	Dimension (W x H x D)	198 x 57 x 143.8 mm
	Construction	Aluminum + SGCC
	Weight	With POE Board: 2.2 kg Without POE Board: 2.1 kg
	Mounting	Rack, VESA, Wallmount, DIN-rail
Driver Support	Microsoft Windows	Win 7/Win 10 Full
Certification	EMC	CE,FCC Class A

Front Panel



No.	Description	
F1	GbE & PoE Ports	6 x 100/1000Mbps Ethernet ports or 4x 100/1000Mbps PoE ports + 2x 100/1000Mbps Ethernet ports (by SKU)
F2	USB Port	2x USB 3.0 port
F3	LED Indicators	<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">HDD Activity</div>  <div style="margin-right: 10px;">WWAN Connection</div>  <div style="margin-right: 10px;">Status System Power</div>  </div> <p>Please refer to Appendix A: LED Indicator Explanations for description of the LED Indicators (including those on GbE Ports and Power Button)</p>
F4	Serial Port	1x DB9 Male connector, RS-232/422/485
F5	Antenna Port	2x Antenna Hole with dust plug

Rear Panel




No.	Description	
R1	Power Button	1x Power button with LED
R2	USB Port	2x USB 2.0 port
R3	HDMI Port	1x HDMI with screw
R4	Serial Port	1x DB9 Male connector, RS-232/422/485
R5	Power Supply	DC 24VDC, 2.5A 60W/120W, 2-pin terminal block
R6	Reset Button	Hardware reset

CHAPTER 2: MOTHERBOARD INFORMATION


Block Diagram

The block diagram indicates how data flows among components on the motherboard. Please refer to the following figure for your motherboard's layout design.


LEC-2137A




LEC-2137B




LEC-2137C






Motherboard Layout

The motherboard layout shows the connectors and jumpers on the board. Refer to the following picture as a reference of the pin assignments and the internal connectors.



Internal Jumper & Connectors

MSATA1



Pin	Description	Pin	Description	Pin	Description	Pin	Description
1	WAKE#	2	+3.3Vaux	3	COEX1	4	GND
5	COEX2	6	+1.5V	7	CLKREQ#	8	UIM_PWR
9	GND	10	UIM_DATA	11	REFCLK+	12	UIM_CLK
13	REFCLK-	14	UIM_RESET	15	GND	16	UIM_VPP
17	Reserve	18	GND	19	Reserve	20	W_DISABLE#
21	GND	22	PERST#	23	PERn0	24	+3.3Vaux
25	PERp0	26	GND	27	GND	28	+1.5V
29	GND	30	SMB_CLK	31	PETn0	32	SMB_DATA
33	PETp0	34	GND	35	GND	36	USB_D-
37	GND	38	USB_D+	39	+3.3Vaux	40	GND
41	+3.3Vaux	42	LED_WWAN#	43	GND	44	LED_WLAN#
45	Reserve	46	LED_WPAN#	47	Reserve	48	+1.5V
49	Reserve	50	GND	51	Reserve	52	+3.3Vaux


SATA1

Pin	Description	Pin	Description
1	GND	2	TXP
3	TXN	4	GND
5	RXN	6	RXP
7	GND		




SATAPWR1

Pin	Description	Pin	Description
1	+12V	2	GND
3	GND	4	+5V



MPCIE1: Mini-PCIe socket with SIM card reader



Pin	Description	Pin	Description	Pin	Description	Pin	Description
1	WAKE#	2	+3.3Vaux	3	COEX1	4	GND
5	COEX2	6	+1.5V	7	CLKREQ#	8	UIM_PWR
9	GND	10	UIM_DATA	11	Reserve	12	UIM_CLK
13	Reserve	14	UIM_RESET	15	GND	16	UIM_VPP
17	Reserve	18	GND	19	Reserve	20	W_DISABLE#
21	GND	22	PERST#	23	Reserve	24	+3.3Vaux
25	Reserve	26	GND	27	GND	28	+1.5V
29	GND	30	Reserve	31	Reserve	32	Reserve
33	Reserve	34	GND	35	GND	36	USB_D-
37	GND	38	USB_D+	39	+3.3Vaux	40	GND
41	+3.3Vaux	42	LED_WWAN#	43	GND	44	LED_WLAN#
45	Reserve	46	LED_WPAN#	47	Reserve	48	+1.5V
49	Reserve	50	GND	51	Reserve	52	+3.3Vaux


SIM1

Pin	Description	Pin	Description
C1	UIM_PWR	C5	GND
C2	UIM_RST#	C6	UIM_VPP
C3	UIM_CLK	C7	UIM_DATA




JRI1 (Pin Header)

Setting	Description
	1-2 (Default): RI#
	3-4: +5V
	5-6: +12V






JSPI1 (Pin Header)

Pin	Description	Pin	Description
1	HOLD#	2	NC
3	CS#	4	+1.8V
5	MISO	6	NC
7	NC	8	CLK
9	GND	10	MOSI



JCMOS1 & 2: (Pin Header)


Setting	Description	Setting	Description
	1-2: Normal (Default)		2-3: Clear CMOS



Note: For your selection of CMOS function to work (Normal or Clear CMOS), please make sure you have configured both the settings on both CMOS1 and CMOS2.

LPC1: (Pin Header)

Pin	Description	Pin	Description
1	CLK	2	AD1
3	RESET#	4	AD0
5	FRAME#	6	+3.3V
7	AD3	8	GND
9	AD2	10	GND



CHAPTER 3: HARDWARE SETUP

To reduce the risk of personal injury, electric shock, or damage to the unit, please remove all power connections to completely shut down the device. Also, please wear ESD protection gloves when conducting the steps in this chapter.

Opening the Chassis

1. Flip over the system and unscrew the four screws indicated in the picture.




2. Insert your fingers into both grooves on the bottom panel and lift the panel up to remove it.



Remove the PoE Power Board

As certain components and connectors such as the SODIMM slot are topped by the PoE Power board, you will have to remove this board in order to reach these components.


Simply remove the four screws that lock the board to the motherboard to reveal the covered components.




Installing the System Memory

The motherboard supports SODIMM memory. Please follow the steps below to install the SODIMM memory modules.

1. Follow the instructions in Remove the PoE Power Board to reveal the SODIMM slot.




2. Align the notch of the module with the socket key in the slot.
3. Press on the card to push it down vertically until it clicks into place.



Installing the mSATA

The motherboard provides one mSATA slot. Follow the procedures below for installing an mSATA card.


1. Locate the mSATA slot.



2. Align the notch of the mSATA module with the socket key in the slot, and insert it at 30 degrees into the socket until it is fully seated in the connector.




3. Push down on the module and secure it with the screw that comes with it.



Installing 3G Supported Module

1. Locate MPCIE1 slot.




To install the SIM card:


2. Slide open the socket cover and lift the cover on its hinges.



3. Insert the SIM card into the slot in the cover with the gold contacts facing down, and the angled corner of the card is positioned correctly as shown in the picture.




4. Push down the cover to close, and the SIM card will come in contact with the metal contacts in the socket. Finally, Slide the socket cover to the Lock position.




To install the 3G module

5. Align the notch of the module with the socket key in the slot, and insert it at 30 degrees into the socket until it is fully seated in the connector.




6. Push down on the module and secure it with the screw that comes with it.



Installing the Disk Drive

1. Fix the hard disk onto the inner side of the bottom panel with provided disk screws.
2. Insert the end of the SATA cable to the SATA contacts on the disk.
3. Insert the other end of the SATA data cable to the SATA port on the motherboard and the end of the SATA power cable to the SATA Power port.



CHAPTER 4: BIOS SETUP

Enter BIOS Setup


To enter the BIOS setup utility, simply follow the steps below:

1. Boot up the system.
2. Pressing the **<Tab>** or **** key immediately allows you to enter the Setup utility, then you will be directed to the BIOS main screen.
3. Instructions of BIOS navigations:

Control Keys	Description
→←	select a setup screen, for instance, [Main], [IntelRCSetup], [Security], [Boot], and [Save & Exit]
↑↓	select an item/option on a setup screen
<Enter>	select an item/option or enter a sub-menu
+/-	to adjust values for the selected setup item/option
F1	to display General Help screen
F2	to retrieve previous values, such as the parameters configured the last time you had entered BIOS.
F3	to load optimized default values
F4	to save configurations and exit BIOS
<Esc>	exit the current screen

Main

Setup main page displays a description of BIOS information and project version information. You can also set up the System Time and System Date here.




(The screenshots presented in section are for reference only)

Item	Description
System Date	The option allows the user to set the date on the system RTC. Simply navigate to the month, day, or year and type in the correct numeric value.
System Time	The option allows the user to set the Time on the system RTC. Simply navigate to the hour, minute, or second and type in the correct numeric value.


Advanced Setup

Use [←] / [→] to select [Advanced] setup screen. Under this screen, you may use [↑] [↓] to select an item you want to configure.




Trusted Computing

This option allows you to turn on/off the BIOS support for security device. Press <Enter> to access the submenu. The default is "Enabled".




Super IO Configuration

This option allows you to configure parameters about Super IO Chip. Press "Enter " to access the submenu.




Serial port 1 Configuration



Item	Value	Description
Serial Port	Enabled Disabled	Enable or Disable Serial Port 1.
Device Settings	NA	IO=3F8h; IRQ = 4
Com1 MODE	RS232 RS485 RS422	Select Com Mode as RS232/RS485/RS422 .

H/W Monitor


This option allows you to monitor the PC Health status.



Item	Description
CPU Temp	This value reports the CPU temperature.
system Temp	This value reports the overall System temperature.
CPU VCORE	This value reports the CPU VCORE.
VSB5V	This value reports the VSB5V Input voltage.
3.3V	This value reports the 3.3V Input voltage.
VBAT	This value reports the VBAT Input voltage.

Watch Dog Timer Configuration


This option allows you to enable or disable Watchdog Timer function. The default is "Disabled".



Item	Value	Description
Watch Dog Timer	Enabled Disabled	Enable or Disable Watch Dog function
Timer Count Mode	Second Mode Minute Mode	Select Second Mode or Minute Mode
Timer out Value	1~255	Watch Dog Timer out Value

POE Configuration


This option allows you to configure PoE GPIO pin output setting.



Item	Value	Description
POE GPIO Pin 1	Output Low Output High	Configuration POE GPIO Pin 1
POE GPIO Pin 2	Output Low Output High	Configuration POE GPIO Pin 2
POE GPIO Pin 3	Output Low Output High	Configuration POE GPIO Pin 3
POE GPIO Pin 4	Output Low Output High	Configuration POE GPIO Pin 4

Serial Port Console Redirection


This option allows you to configure parameters about serial port console redirection. Press “Enter” to access the submenu. The default is “Enabled”.



Item	Value	Description
Console Redirection	Disabled Enabled	Console Redirection Enabled or Disabled

Console Redirection Settings

Select this item to enter the setting sub-menu. These settings specify how the host computer and the remote computer will exchange data. Both computers should have the same or compatible settings.




Item	Value	Description
Terminal Type	VT100	ANSI: Extended ASCII char set.
	VT100+	VT100: ASCII char set.
	VT-UTF8	VT100+: Extends VT100 to support color, function keys, etc.
	ANSI	VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
Bits per second	9600	Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
	19200	
	38400	
	57600	
	115200	
Data Bits	7	Data Bits
	8	
Parity	None	A parity bit can be sent with the data bits to detect some transmission errors.
	Even	

	Odd Mark Space	
Stop Bits	1 2	Stop bits indicate the end of a serial data packet.
Flow Control	None Hardware RTS/CTS	Flow control can prevent data loss from buffer overflow.
VT-UTF8 Combo Key Support	Disabled Enabled	Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals
Recorder Mode	Disabled Enabled	With this mode enabled only text will be sent. This is to capture Terminal data.
Putty KeyPad	VT100 LINUX XTERM86 SCO ESCN VT400	Select FunctionKey and KeyPad on Putty.

CPU Configuration

This option allows you to configure socket specific CPU information.



Socket 0 CPU Information

Aptio Setup Utility - Copyright (C) 2017 American Megatrends, Inc.

Advanced


Socket 0 CPU Information		
Intel(R) Celeron(R) CPU N3350 @ 1.10GHz		
CPU Signature	506C9	
Microcode Patch	28	
Max CPU Speed	1100 MHz	
Min CPU Speed	800 MHz	
Processor Cores	2	
Intel HT Technology	Not Supported	
Intel VT-x Technology	Supported	
L1 Data Cache	24 kB x 2	
L1 Code Cache	32 kB x 2	
L2 Cache	1024 kB x 2	
L3 Cache	Not Present	

++: Select Screen
 ↑↓: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F2: Previous Values
 F3: Optimized Defaults
 F4: Save & Exit
 ESC: Exit

Version 2.18.1263. Copyright (C) 2017 American Megatrends, Inc.

AB


CPU Power Management Configuration



Item	Value	Description
EIST	Disabled Enabled	Enable/Disable Intel SpeedStep
Turbo Mode	Disabled Enabled	Enable/Disable Turbo mode

CSM Configuration

This option allows you to enable or disable ROM execution settings.




Item	Value	Description
CSM Support	Disabled Enabled	Enable/Disable CSM Support
Network	Do Not Launch UEFI Legacy	Controls the execution of UEFI and Legacy PXE OpROM
Storage	Do Not Launch UEFI Legacy	Controls the execution of UEFI and Legacy Storage OpROM
Video	Do Not Launch UEFI Legacy	Controls the execution of UEFI and Legacy Video OpROM
Other PCI device	Do Not Launch UEFI Legacy	Determines OpROM execution policy for devices other than Network, Storage, or Video

USB Configuration


This option allows you to change USB configuration parameters.

Legacy USB Support



Item	Value	Description
Legacy USB Support	Auto Enabled Disabled	Enables Legacy USB support. “Auto” disables legacy support if no USB devices are connected. “Disabled” will keep USB devices available only for EFI applications. The default is “Enabled” .

LAN Boot Configuration



Item	Value	Description
PXE Function	LAN1 Disabled	Select On-Board LAN for enabling PXE boot function.

Processor Configuration

```

Aptio Setup Utility - Copyright (C) 2017 American Megatrends, Inc.
IntelRCSetup

Processor Configuration
Processor ID          000506F1
Processor Frequency   2.000GHZ
CPU BCLK Frequency    100MHZ
L1 Cache RAM          56KB
L2 Cache RAM          2048KB
Processor Version     Intel(R) Atom(TM) CPU
                     C3958 @ 2.00GHZ

EIST (GV3)           [Disable]
CPU C State          [Disable]


Enable/Disable EIST.
GV3 and TM1 must be
enabled for TM2 to be
available. GV3 must be
enabled for Turbo. Auto
- Enable for B0 CPU
stepping, all others
disabled, change

-----
++: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.19.1266. Copyright (C) 2017 American Megatrends, Inc.
    
```


Item	Value	Description
EIST(GV3)	Disable Enabled	Enable/Disable EIST. GV3 and TM1 must be enabled for TM2 to be available. GV3 must be enabled for <u>Turbo</u> . Auto - Enable for B0 CPU stepping, all others disabled, change setting to override.
CPU C State	Disabled Enabled	"Enables the Enhanced Cx state of the CPU, takes effect after a reboot. Auto - Enable for B0 CPU stepping, all others disabled, change setting to override.

Chipset




North Bridge

This option enables or disables fast boot which skips memory training and attempts to boot using last known good configuration. The default is "Enabled".




Item	Value	Description
Max TOLUD	2 GB	Maximum Value of TOLUD
	2.25 GB	
	2.5 GB	
	2.75 GB	
	3 GB	

South Bridge




Item	Value	Description
OS Selection	Windows Android Win 7 Intel Linux	Select the target OS


South Cluster Configuration



SATA Driver



Miscellaneous Configuration




Item	Value	Description
High Precision Timer	Disabled Enabled	Enable or Disable the High Precision Event Timer
Restore AC Power Loss	Power On Power Off Last State	Specify what state to go to when power is re-applied after a power failure (G3 State). S0 state: System will boot directly as soon as power applied.

Security

Use [←] / [→] to select [Security] setup screen. Under this screen, you may use [↑] [↓] to select an item you would like to configure.


Administrator Password & User Password:



Item	Description
Administrator Password	If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup.
User Password	If ONLY the User's password is set, then this is a power-on password and must be entered to boot or enter Setup. In Setup, the User will have Administrator rights.


Secure Boot

Enter Secure Boot page for more related settings.



Item	Value	Description
Attempt Secure Boot	Disabled Enabled	Secure Boot activated when Platform Key(PK) is enrolled, System mode is User/Deployed, and CSM function is disabled
Secure Boot Mode	Standard Custom	Secure Boot mode selector: In Custom mode, Secure Boot Variables can be configured without authentication


Key Management



Item	Value	Description
Provision Factory Defaults	Disabled Enabled	Allow to provision factory default Secure Boot keys when System is in Setup Mode.
Install Factory Default keys	None	Force System to User Mode - install all Factory Default keys
Enroll Efi Image	None	Allow the image to run in Secure Boot mode. Enroll SHA256 hash of the binary into Authorized Signature Database (db)

Boot Menu


Select the Boot menu item from the BIOS setup screen to enter the [Boot] Setup screen.



Item	Value	Description
Quiet Boot	Disabled Enabled	Enables or disables Quiet Boot option.
Boot mode select	LEGACY UEFI	Select boot mode LEGACY/ UEFI .


Save and Exit Menu

Select the Save and Exit menu item from the BIOS setup screen to enter the [Save and Exit] Setup screen. Users can select any of the items in the left frame of the screen.




Save Changes and Exit

When you have completed the system configuration, select this option to save the changes and Exit from BIOS Setup, so the new system configuration parameters can take effect. This window will appear after the 'Save Changes and Exit' option is selected. Select **YES** to save changes and exit Setup.




Discard Changes and Exit

Select this option to quit Setup without saving any modifications to the system configuration. This window will appear after the 'Discard Changes and Exit' option is selected. Select **YES** to discard changes and exit Setup.



Restore Defaults

Restore default values for all setup options. Select **YES** to load Optimized Defaults.




APPENDIX A: LED INDICATOR EXPLANATIONS

The status explanations of LED indicators on Front Panel are as follows:

Power Button

		
<p>Power-Off mode: The system is not connected to any power source.</p>	<p>Stand-by mode: The system is connected with power source; ready for powering up with a push on the button.</p>	<p>Power-On mode: The system is powered on. Perform a graceful shutdown using the service commands to ensure that all of your data is saved.</p>

Status LED



▶ System Power

<i>Solid Green</i>	The system is powered on
<i>Off</i>	The system is powered off


▶ WWAN Connection

<i>Solid Green</i>	The system is connected with WWAN network.
<i>Blinking Green</i>	The system is transmitting/receiving data via WWAN connection
<i>Off</i>	

▶ HDD Activity

<i>Blinking Amber</i>	Data access activity
<i>Off</i>	No data access activity

GbE & PoE Ports



▶ Link Activity


<i>Blinking Amber</i>	Link has been established and there is activity on this port
<i>Solid Amber</i>	Link has been established and there is no activity on this port
<i>Off</i>	No link has been established

▶ Speed

<i>Off</i>	Operating as a 10-Mbps connection
<i>Solid Green</i>	Operating as a 100-Mbps connection

APPENDIX B: PROGRAMMING WATCHDOG TIMER

A watchdog timer is a piece of hardware that can be used to automatically detect system anomalies and reset the processor in case there are any problems. Generally speaking, a watchdog timer is based on a counter that counts down from an initial value to zero. The software selects the counter's initial value and periodically restarts it. Should the counter reach zero before the software restarts it, the software is resumed to be malfunctioning and the processor's reset signal is asserted. Thus, the processor will be restarted as if a human operator had cycled the power.



To execute the utility: enter the number of seconds to start the countdown before the system can be reset.

```
wd_tst -swt xxx (Set Watchdog Timer 1-255 seconds and start to count-down)
```

```
wd_tst -stop (Stop Watchdog Timer)
```

- For a reference utility that contains sample code for watchdog function programming, please visit <http://www.lannerinc.com/support/download-center/drivers>, enter the product category and download the utility package of LEC-2137.

APPENDIX C: SETTING UP CONSOLE REDIRECTIONS

Console redirection lets you monitor and configure a system from a remote terminal computer by re-directing keyboard input and text output through the serial port. The following steps illustrate how to use this feature. The BIOS of the system allows the redirection of the console I/O to a serial port. With this configured, you can remotely access the entire boot sequence through a console port.

1. Connect one end of the console cable to console port of the system and the other end to the serial port of the Remote Client System.
2. Configure the following settings in the BIOS Setup menu:
BIOS > Advanced > Serial Port Console Redirection > Console Redirection Settings, select **115200** for the Baud Rate, **None** for Flow control, **8** for the Data Bit, **None** for Parity Check, and **1** for the Stop Bit.
3. Configure console redirection related settings on the client system. You can use a terminal emulation program that features communication with serial COM ports such as *TeraTerm* or *Putty*. Make sure the serial connection properties of the client conform to those set in Step 1 for server.

APPENDIX D: INSTALLING INTEL® LAN CONTROLLER DRIVER FOR LINUX

To install the Intel® LAN controller base driver for the Red Hat® and Linux operating system, please visit <http://www.lannerinc.com/support/download-center/drivers>, enter the product category and download the utility package of LEC-2137.

For the latest driver update, please visit Intel® download center at <https://downloadcenter.intel.com/>, use the keyword search or the filter to access the driver's product page, and then download the latest controller driver as well as the ReadMe document.

Product Name Keyword	I210
Product Category	Ethernet Products → Gigabit Ethernet Controllers → Intel® Ethernet Server Adapter I210 Series
Download Type	Drivers
Operating System	Linux*
Product page	Intel® Network Adapter Driver for 82575/6, 82580, I350, and I210/211-Based Gigabit Network Connections for Linux*

APPENDIX E: TERMS AND CONDITIONS

Warranty Policy

1. All products are under warranty against defects in materials and workmanship for a period of one year from the date of purchase.
2. The buyer will bear the return freight charges for goods returned for repair within the warranty period; whereas the manufacturer will bear the after service freight charges for goods returned to the user.
3. The buyer will pay for the repair (for replaced components plus service time) and transportation charges (both ways) for items after the expiration of the warranty period.
4. If the RMA Service Request Form does not meet the stated requirement as listed on "RMA Service," RMA goods will be returned at customer's expense.
5. The following conditions are excluded from this warranty:
 - ▶ Improper or inadequate maintenance by the customer
 - ▶ Unauthorized modification, misuse, or reversed engineering of the product
 - ▶ Operation outside of the environmental specifications for the product.

RMA Service

Requesting an RMA#

1. To obtain an RMA number, simply fill out and fax the "RMA Request Form" to your supplier.
2. The customer is required to fill out the problem code as listed. If your problem is not among the codes listed, please write the symptom description in the remarks box.
3. Ship the defective unit(s) on freight prepaid terms. Use the original packing materials when possible.
4. Mark the RMA# clearly on the box.



Note: Customer is responsible for shipping damage(s) resulting from inadequate/loose packing of the defective unit(s). All RMA# are valid for 30 days only; RMA goods received after the effective RMA# period will be rejected.

RMA Service Request Form

When requesting RMA service, please fill out the following form. Without this form enclosed, your RMA cannot be processed.

RMA No:	Reasons to Return: <input type="checkbox"/> Repair(Please include failure details) <input type="checkbox"/> Testing Purpose
Company:	Contact Person:
Phone No.	Purchased Date:
Fax No.:	Applied Date:
Return Shipping Address: _____	
Shipping by: <input type="checkbox"/> Air Freight <input type="checkbox"/> Sea <input type="checkbox"/> Express _____	
<input type="checkbox"/> Others: _____	

Item	Model Name	Serial Number	Configuration

Item	Problem Code	Failure Status

***Problem Code:**

- | | | | |
|------------------------|------------------------------|--------------------|--------------------------|
| 01: D.O.A. | 07: BIOS Problem | 13: SCSI | 19: DIO |
| 02: Second Time R.M.A. | 08: Keyboard Controller Fail | 14: LPT Port | 20: Buzzer |
| 03: CMOS Data Lost | 09: Cache RMA Problem | 15: PS2 | 21: Shut Down |
| 04: FDC Fail | 10: Memory Socket Bad | 16: LAN | 22: Panel Fail |
| 05: HDC Fail | 11: Hang Up Software | 17: COM Port | 23: CRT Fail |
| 06: Bad Slot | 12: Out Look Damage | 18: Watchdog Timer | 24: Others (Pls specify) |

Request Party

Confirmed By Supplier

Authorized Signature / Date

Authorized Signature / Date