

Lanner

Network Appliance Platform

Hardware Platforms for Network Computing

NCA-6520 User Manual

Version: 1.8

Date of Release:2024-04-17

About this Document

This manual describes the overview of the various functionalities of this product, and the information you need to get it ready for operation. It is intended for those who are:

- responsible for installing, administering and troubleshooting this system or Information Technology professionals.
- assumed to be qualified in the servicing of computer equipment, such as professional system integrators, or service personnel and technicians.

The latest version of this document can be found on Lanner's official website, available either through the product page or through the [Lanner Download Center](#) page with a login account and password.

Icon Description

The icons are used in the manual to serve as an indication of interest topics or important messages.

Icon	Usage
 Note or Information	This mark indicates that there is something you should pay special attention to while using the product.
 Warning or Important	This mark indicates that there is a caution or warning and it is something that could damage your property or product.

Online Resources

To obtain additional documentation resources and software updates for your system, please visit the [Lanner Download Center](#). As certain categories of documents are only available to users who are logged in, please be registered for a Lanner Account at <http://www.lannerinc.com/> to access published documents and downloadable resources.

Technical Support

In addition to contacting your distributor or sales representative, you could submit a request at our [Lanner Technical Support](#) and fill in a support ticket to our technical support department.

Documentation Feedback

Your feedback is valuable to us, as it will help us continue to provide you with more accurate and relevant documentation. To provide any feedback, comments or to report an error, please email contact@lannerinc.com. Thank you for your time.

Copyright and Trademarks

This document is copyrighted © 2024 by Lanner Electronics Inc. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, nor for any infringements upon the rights of third parties that may result from such use.

Contact Information

Taiwan Corporate Headquarters

Lanner Electronics Inc.

7F, No.173, Sec.2, Datong Rd.
Xizhi District, New Taipei City 22184,
Taiwan

立端科技股份有限公司

221 新北市汐止區
大同路二段 173 號 7 樓

T: +886-2-8692-6060

F: +886-2-8692-6101

E: contact@lannerinc.com

USA

Lanner Electronics Inc.

47790 Westinghouse Drive
Fremont, CA 94539

T: +1-855-852-6637

F: +1-510-979-0689

E: sales_us@lannerinc.com

Europe

Lanner Europe B.V.

Wilhelmina van Pruisenweg 104
2595 AN The Hague
The Netherlands

T: +31 70 701 3256

E: sales_eu@lannerinc.com

China

Beijing L&S Lancom Platform Tech. Co., Ltd.

Guodong LOFT 9 Layer No. 9 Huinan Road,
Huilongguan Town, Changping District, Beijing
102208 China

T: +86 010-82795600

F: +86 010-62963250

E: service@ls-china.com.cn

Canada

Lanner Electronics Canada Ltd

3160A Orlando Drive
Mississauga, ON
L4V 1R5 Canada

T: +1 877-813-2132

F: +1 905-362-2369

E: sales_ca@lannerinc.com

Acknowledgment

Intel® and Intel® Celeron® are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries. Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp. All other product names or trademarks are properties of their respective owners.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ Reorient or relocate the receiving antenna.
- ▶ Increase the separation between the equipment and receiver.
- ▶ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

- ▶ Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- ▶ This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Note

1. An unshielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.
2. Use only shielded cables to connect I/O devices to this equipment.
3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Important

1. Operations in the 5.15-5.25GHz band are restricted to indoor usage only.
2. This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.

Safety Guidelines

Follow these guidelines to ensure general safety:

- ▶ Keep the chassis area clear and dust-free during and after installation.
- ▶ Do not wear loose clothing or jewelry that could get caught in the chassis. Fasten your tie or scarf and roll up your sleeves.
- ▶ Wear safety glasses if you are working under any conditions that might be hazardous to your eyes.
- ▶ Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- ▶ Disconnect all power by turning off the power and unplugging the power cord before installing or removing a chassis or working near power supplies
- ▶ Do not work alone if potentially hazardous conditions exist.
- ▶ Never assume that power is disconnected from a circuit; always check the circuit.

Consignes de sécurité

Suivez ces consignes pour assurer la sécurité générale :

- ▶ Laissez la zone du châssis propre et sans poussière pendant et après l'installation.
- ▶ Ne portez pas de vêtements amples ou de bijoux qui pourraient être pris dans le châssis. Attachez votre cravate ou écharpe et remontez vos manches.
- ▶ Portez des lunettes de sécurité pour protéger vos yeux.
- ▶ N'effectuez aucune action qui pourrait créer un danger pour d'autres ou rendre l'équipement dangereux.
- ▶ Coupez complètement l'alimentation en éteignant l'alimentation et en débranchant le cordon d'alimentation avant d'installer ou de retirer un châssis ou de travailler à proximité de sources d'alimentation.
- ▶ Ne travaillez pas seul si des conditions dangereuses sont présentes.
- ▶ Ne considérez jamais que l'alimentation est coupée d'un circuit, vérifiez toujours le circuit. Cet appareil génère, utilise et émet une énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions des fournisseurs de composants sans fil, il risque de provoquer des interférences dans les communications radio.

Lithium Battery Caution

- ▶ There is risk of explosion if the battery is replaced by an incorrect type.
- ▶ Dispose of used batteries according to the instructions.
- ▶ Installation should be conducted only by a trained electrician or only by an electrically trained person who knows all installation procedures and device specifications which are to be applied.
- ▶ Do not carry the handle of power supplies when moving to another place.
- ▶ Please conform to your local laws and regulations regarding safe disposal of lithium battery.
- ▶ Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery can result in an explosion.
- ▶ Leaving a battery in an extremely high temperature environment can result in an explosion or the leakage of flammable liquid or gas.
- ▶ A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.

Avertissement concernant la pile au lithium

- ▶ Risque d'explosion si la pile est remplacée par une autre d'un mauvais type.
- ▶ Jetez les piles usagées conformément aux instructions.
- ▶ L'installation doit être effectuée par un électricien formé ou une personne formée à l'électricité connaissant toutes les spécifications d'installation et d'appareil du produit.
- ▶ Ne transportez pas l'unité en la tenant par le câble d'alimentation lorsque vous déplacez l'appareil.

Operating Safety

- ▶ Electrical equipment generates heat. Ambient air temperature may not be adequate to cool equipment to acceptable operating temperatures without adequate circulation. Be sure that the room in which you choose to operate your system has adequate air circulation.
- ▶ Ensure that the chassis cover is secure. The chassis design allows cooling air to circulate effectively. An open chassis permits air leaks, which may interrupt and redirect the flow of cooling air from internal components.
- ▶ Electrostatic discharge (ESD) can damage equipment and impair electrical circuitry. ESD damage occurs when electronic components are improperly handled and can result in complete or intermittent failures. Be sure to follow ESD-prevention procedures when removing and replacing components to avoid these problems.

- ▶ Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. If no wrist strap is available, ground yourself by touching the metal part of the chassis.
- ▶ Periodically check the resistance value of the antistatic strap, which should be between 1 and 10 megohms (Mohms).

Sécurité de fonctionnement

- ▶ L'équipement électrique génère de la chaleur. La température ambiante peut ne pas être adéquate pour refroidir l'équipement à une température de fonctionnement acceptable sans circulation adaptée. Vérifiez que votre site propose une circulation d'air adéquate.
- ▶ Vérifiez que le couvercle du châssis est bien fixé. La conception du châssis permet à l'air de refroidissement de bien circuler. Un châssis ouvert laisse l'air s'échapper, ce qui peut interrompre et rediriger le flux d'air frais destiné aux composants internes.
- ▶ Les décharges électrostatiques (ESD) peuvent endommager l'équipement et gêner les circuits électriques. Des dégâts d'ESD surviennent lorsque des composants électroniques sont mal manipulés et peuvent causer des pannes totales ou intermittentes. Suivez les procédures de prévention d'ESD lors du retrait et du remplacement de composants.
- ▶ Portez un bracelet anti-ESD et veillez à ce qu'il soit bien au contact de la peau. Si aucun bracelet n'est disponible, reliez votre corps à la terre en touchant la partie métallique du châssis.
- ▶ Vérifiez régulièrement la valeur de résistance du bracelet antistatique, qui doit être comprise entre 1 et 10 mégohms (Mohms).

Mounting Installation Precautions

The following should be put into consideration for rack-mount or similar mounting installations:

- ▶ Do not install and/or operate this unit in any place that flammable objects are stored or used in.
- ▶ The installation of this product must be performed by trained specialists; otherwise, a non-specialist might create the risk of the system's falling to the ground or other damages.
- ▶ Lanner Electronics Inc. shall not be held liable for any losses resulting from insufficient strength for supporting the system or use of inappropriate installation components.
- ▶ Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T_{ma}) specified by the manufacturer.
- ▶ Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.
- ▶ Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
- ▶ Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
- ▶ Reliable Grounding - Reliable grounding of rack mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).
- ▶ Instruction for the installation of the conductor to building earth by a skilled person.

Electrical Safety Instructions


Before turning on the device, ground the grounding cable of the equipment. Proper grounding (grounding) is very important to protect the equipment against the harmful effects of external noise and to reduce the risk of electrocution in the event of a lightning strike. To uninstall the equipment, disconnect the ground wire after turning off the power. A ground wire (green-and-yellow) is required and the part connecting the conductor must be greater than 6 mm² or 8AWG.

Consignes de sécurité électrique

- ▶ Avant d'allumer l'appareil, reliez le câble de mise à la terre de l'équipement à la terre.
- ▶ Une bonne mise à la terre (connexion à la terre) est très importante pour protéger l'équipement contre les effets néfastes du bruit externe et réduire les risques d'électrocution en cas de foudre.
- ▶ Pour désinstaller l'équipement, débranchez le câble de mise à la terre après avoir éteint l'appareil.
- ▶ Un câble de mise à la terre est requis et la zone reliant les sections du conducteur doit faire plus de 6 mm² ou 8 AWG.


Grounding Procedure for This Device

- ▶ Connect the grounding cable to the ground.
- ▶ The protection device for the DC power source must provide 40A current.
- ▶ This protection device must be connected to the power source before DC power.



Procédure de mise à la terre l'équipement

- ▶ Branchez le câble de mise à la terre à la terre.
- ▶ L'appareil de protection pour la source d'alimentation CC doit fournir 40A de courant.
- ▶ Cet appareil de protection doit être branché à la source d'alimentation avant l'alimentation CC.



Warning

- ▶ This equipment must be grounded. The power cord for product should be connected to a socket-outlet with earthing connection.
- ▶ Product shall be used with Class 1 laser device modules.
- ▶ Suitable for installation in Information Technology Rooms in accordance with Article 645 of the National Electrical Code and NFPA 75.
- ▶ The machine can only be used in a restricted access location and be installed and serviced by skilled person.

Avertissement

- ▶ Cet équipement doit être mis à la terre. La fiche d'alimentation doit être connectée à une prise de terre correctement câblée
- ▶ Le produit doit être utilisé avec des modules de dispositifs laser de classe 1.
- ▶ Peut être installé dans des salles de matériel de traitement de l'information conformément à l'article 645 du National Electrical Code et à la NFPA 75.
- ▶ Les matériels sont destinés à être installés dans des EMBLEMES À ACCÈS RESTREINT.

For DC input, this unit is intended to be supplied by an UL listed power source, rated 48 to 72Vdc, 40A min, and an altitude operation 5000m min.



CAUTION: TO DISCONNECT POWER, REMOVE ALL POWER CORDS FROM UNIT.

注意：要断开电源，请将所有电源线从本机上拔下。
注意：要斷開電源，請將所有電源線從本機上拔下。

WARNING: Wenn Sie das Gerät zwecks Wartungsarbeiten vom Netz trennen müssen, müssen Sie beide Netzteile abnehmen.

ATTENTION: DÉBRANCHER TOUS LES CORDONS D'ALIMENTATION POUR DÉCONNECTER L'UNITÉ DU SECTEUR.

Table of Contents

Chapter 1: Product Overview	10
Ordering Information	10
Optional Accessories	11
System Specifications	12
Front Panel	13
Rear Panel.....	14
Chapter 2: Motherboard Information	16
Motherboard Layout	17
Internal Jumper & Connectors	18
Chapter 3: Hardware Setup	30
Opening the Chassis	30
Installing the CPU	31
Installing the System Memory.....	37
Installing TPM Module (Optional)	40
Installing the Riser Converter Card (Optional)	41
Installing the Disk Drive(s) (Optional).....	43
Installing the NIC Modules (Optional).....	45
Installing the LCM Module (Optional).....	47
Installing the M.2 SSD memory card (Optional).....	49
Installing the GPU graphic card (Optional).....	50
NFVI Platform Configure Installation (Optional)	54
Replacing the Cooling Fans.....	55
Replacing the Power Supply Units	57
Mounting the System	58

Install DC Power Supply..... 63

Chapter 4: Remote Server Management 64

BMC Main Features 64

BMC Firmware Functional Description 65

IPMI Commands Support List 67

Using BMC Web UI 69

Chapter 5: BIOS Setup 74

Advanced Setup..... 76

Platform Setup..... 97

Socket Setup 104

Server Mgmt Setup..... 121

Security Setup..... 126

Boot Setup 129

Save and Exit Setup 130

Appendix A: LED INDICATOR EXPLANATIONS..... 132

Appendix B: DUAL BIOS INTRODUCTION 134

Appendix C: REDUNDANT POWER MODULE BEHAVIOR 136

Appendix D: FAN SEQUENCE..... 137

Appendix E: SMART POWER & RESET BUTTON 138

Appendix F: ESD/SURGE ENHANCEMENT..... 139

Appendix G: TERMS AND CONDITIONS 140

Warranty Policy 140

CHAPTER 1: PRODUCT OVERVIEW

Thank you for choosing NCA-6520. NCA-6520 is a 2U 19" rackmount network security appliance featuring dual 3rd Gen Intel® Xeon® Scalable Processor, higher throughputs, built-in crypto acceleration and exceptional NIC module expansion. NCA-6520 accommodates up to twenty-four 288-pin DDR4 R-DIMM/LRDIMM at 2133/2400/2666/2933/3200 MHz, providing up to 1536GB of system memory. Other notable features include 2x HDD/SSD drive bays, 1300W/2000W 1+1 ATX redundant powers, 2x PCI-E *16 expansion slots, 3x M.2 and 4x individual hot-swappable smart fans.

Package Content

Your package contains the following items:

- 1x NCA-6520 Network Security Platform
- 2x Power Cable
- 1x RJ45 Console Cable
- 1x RJ45 LAN Cable
- 1x RJ45 Cross-over LAN Cable
- 2x Short Ear Rack Mount Kit with Screws
- 10x 3.5" HDD Screws, 10x 2.5" HDD Screws
- 2x Processor Carrier
- 2x CPU Heatsink

Ordering Information

SKU No.	Description
NCA-6520A	2x Ice Lake-SP (270W) / PCH C627A / 2x GbE RJ45 MGMT / AST2500 MGMT with 1300W 1+1 redundant PSU
NCA-6520B	2x Ice Lake-SP (185W) / PCH C627A / 2x GbE RJ45 MGMT / AST2500 MGMT with 2000W 1+1 redundant PSU /support GPU card

Optional Accessories

Model	Description
NCS2-LCM6210A	LCM module for NCS2 (By ODM/OEM)
IAC-TPM04A	TPM module
RISER CARD KIT RC-U201A	M.2 to U.2 Mini SAS NVMe module card and cable (by project)
850W AC PSU	850W AC power module Note: Both power modules must be inserted concurrently
1600W DC PSU	1600W DC power module
DC PSU Cable	3P Y-Spade Terminal 300 cm Gas power only
FAN KIT 60 NCA-6520A	Swappable FAN kit, suitable for NCA-6520A
FAN KIT 60 NCA-6520B	Swappable FAN kit, suitable for NCA-6520B for GPU PCIE bracket
FAN KIT 40 NCA-6520B	Swappable FAN kit, suitable for NCA-6520B for GPU PCIE bracket
SUB PCIE BRACKET R NCA-6520A	Support PCIE card for NCC-6520A right rear side (by project)
SUB PCIE BRACKET L NCA-6520A	Support PCIE card for NCC-6520A left rear side (by project)
SUB PCIE BRACKET R NCA-6520B	Support PCIE card for NCC-6520B right rear side (by project)
SUB PCIE BRACKET L NCA-6520B	Support PCIE card for NCC-6520B left rear side (by project)
2U SLIDE RAIL KIT	PSF6407-010 (with separate packaging); or 098W000300014 (packaged with system)
QAT Cable	SlimSAS Cable (straight-to-straight), configure system support NFVI optimal platform. (U148, U149 SlimSAS connector): 080W000862000
Gen4 Slim SAS to PCIE cable	High speed PCIe Gen 4 Cable for extend front NIC (pre-installed) PCIEx8 Gen4 Slim SAS to PCIE cable (for front NIC): SFF-8654 X8 *1 to PCIe X8
Gen4 Slim SAS to PCIE cable	High speed PCIe Gen 4 Cable for extend front NIC (pre-installed) PCIEx16 Gen4 Slim SAS to PCIE cable (for rear side): SFF-8654 X8 *2 to PCIe X16




Note: If any component is missing or damaged, please contact your dealer immediately for assistance.

System Specifications

Form Factor		2U 19" Rackmount
Platform	Processor Options	3rd Gen Intel® Xeon® Processor Scalable Family (Ice Lake-SP)
	CPU Socket	2x LGA4189
	Chipset	Intel® C627A
	Security Acceleration	Intel® QuickAssist Technology
BIOS		AMI SPI Flash BIOS
System Memory	Technology	DDR4 2133/2400/2666/2933/3200 MHz R-DIMM / LRDIMM
	Max. Capacity	1536GB
	Socket	24x 288-pin DIMM
Networking	Ethernet Ports	2x GbE RJ45 Intel® i350-AM2
	Bypass	Depends on NIC module specifications
	NIC Module Slot	8x NIC Module Slots
LOM	IO Interface	1x LOM Port via BMC for remote management
I/O Interface	Reset Button	1x Resent Button
	LED Indicators	Power/Status/Storage
	Power Button	1x ATX Power Switch
	Console Port	1x RJ45 Console Port
	USB Port	2x USB 3.0 Port
	LCD Module	N/A (Default); 2x20 Character LCM w/4 x Keypads (Optional)
	Display Port	1x VGA Port (Optional)
Storage	Power Input	AC/DC power inlet on PSU
	HDD/SSD Support	2x 3.5" or 2.5 swappable
	Onboard Slots	2x M.2 NVME 2280; 1x M.2 2280 SATA
Expansion	PCIe	SKU A: N/A (Default); 1x PCIe x16 Gen4 FH/FL single-slot bracket; 1x PCIe x16 Gen4 FH/HL single-slot bracket, up to 75W for each side. (Optional)
		SKU B: N/A (Default); 2x PCIe x16 Gen4 FH/FL dual-slot bracket, up to 300W for each side. (Optional)
Miscellaneous	Watchdog	YES
	Internal RTC with Li Battery	YES
	TPM	TPM 2.0
Cooling	Processor	Passive CPU heat sink
	System	4x individual hot-swappable cooling smart fans
Environmental Parameters	Temperature	0~40°C Operating -20~70°C Non-Operating
	Humidity (RH)	5~90% Operating; 5~ 95% Non-Operating
System Dimensions	(WxDxH)	438 x 720 x 88 mm
	Weight	19.3 kg
Package Dimensions	(WxDxH), Weight	588mm x 997mm x 250mm, 32kg
Power	Type/Watts	SKU A: 1300W AC 1+1 Redundant PSU (Default); SKU B: 2000W AC 1+1 Redundant PSU (Default) 1600W DC 1+1 Redundant Module (Optional)
	Input	AC 90~264V @47~63 Hz
Approvals and Compliance		RoHS, CE Class A, FCC Class A, UL

Front Panel




No.	Description	
F1	Reset Button	1x Software reset button
F2	LED Indicators	 <ul style="list-style-type: none"> System Power System Status HDD Activity
F3	USB Port	2x USB 3.0 Ports
F4	RJ45 Port	2x RJ45 Ports w/ LED for Dual MGT (support PXE; enabled as default)
F5	LOM Port	1x LOM Port for remote management
F6	Console Port	1x RJ45 Console Port
F7	HDD Tray w/ LED Indicators	2x 2.5"/3.5" HDD Tray  <ul style="list-style-type: none"> HDD Status HDD Activity
F8	NCS2 Module	8x Standard NIC Module Slots



Note: Please refer to Appendix A: LED Indicator Explanations for descriptions of the LED Indicators.


Rear Panel

NCA-6520A



No.	Description	
R1	Rear PCIe Expansion	1x PCIe x16 FH/FL Single-slot Bracket at Left Rear Side (optional); 1x PCIe x16 FH/HL Single-slot Bracket at Right Rear Side (optional); Support up to 75W for each side
R2	ESD Jack	1x Semi-Shearing hole for ESD screws
R3	Ground Hole	2x Semi-Shearing hole for grounding screws
R4	Power Switch	1x Power Button
R5	Alarm off Button	An audible alarm will sound when the system's redundant power is missing. Press this button to turn the alarm off.
R6	VGA or Console Port	1x Semi-Shearing hole by DB9 or DB15 (Optional)
R7	USB Port	1x Semi-Shearing hole by USB type (Optional)
R8	Power Supply	2x 1300W AC Redundant (N+1 Design); 1600W DC Redundant (Optional)
R9	Smart Fans	4x Independent Swappable Fans

NCA-6520B




No.	Description	
R1	Rear PCIe Expansion	2x PCIE x16 FH/FL Dual-Slot Bracket at rear side (optional), Support up to 300W for each side
R2	ESD Jack	1x Semi-Shearing hole
R3	Ground Hole	2x Semi-Shearing hole for grounding screws
R4	Power Switch	1x Power Button
R5	Alarm off Button	An audible alarm will sound when the system's redundant power is missing. Press this button to turn the alarm off.
R6	VGA or Console	1x Semi-Shearing hole by DB9 or DB15 (Optional)
R7	USB	1x Semi-Shearing hole by USB type (Optional)
R8	Power Supply	2x 2000W AC Redundant (N+1 Design); 1600W DC Redundant (Optional)
R9	Smart Fans	2x 60mm Swappable Fans, 2x 40mm Swappable Fans

CHAPTER 2: MOTHERBOARD INFORMATION


Block Diagram

The block diagram indicates how data flows among components on the motherboard. Please refer to the following figure for the motherboard layout design.



Motherboard Layout


The motherboard layout shows the connectors and jumpers on the board. Refer to the following picture as a reference of the pin assignments and the internal connectors.



Internal Jumper & Connectors


JUSB1: USB2.0 pin header on board

Pin	Description	Pin	Description
1	+P5V_USB2	2	+P5V_USB2
3	USB20_L_N3	4	USB20_L_N4
5	USB20_L_P3	6	USB20_L_P4
7	USBGND1	8	USBGND1
9	USBGND1	10	USBGND1




PLD1: CPLD pin header

Pin	Description	Pin	Description
1	JTAG_PLD_TCK	2	GND
3	JTAG_PLD_TDO	4	+P3V3_AUX
5	JTAG_PLD_TMS	6	--
7	--	8	--
9	JTAG_PLD_TDI	10	GND




JGP1: DIO pin header for development debug

Pin	Description	Pin	Description
1	GPO_B_1	2	GPI_B_1
3	GPO_B_2	4	GPI_B_2
5	GPO_B_3	6	GPI_B_3
7	GPO_B_4	8	GPI_B_4
9	GND	10	GND




JLPC_80P: 80 port for BIOS code number

Pin	Description	Pin	Description
1	LPC_80PORT_CLK	2	LPC_80PORT_LAD1
3	LPC_80PORT_RST	4	LPC_80PORT_LAD0
5	LPC_80PORT_LFRAME	6	+P3V3
7	LPC_80PORT_LAD3	8	--
9	LPC_80PORT_LAD2	10	GND




JBMCSPIROM1: Recovery BMC firmware

Pin	Description	Pin	Description
1	BMC_SPI_HD1#	2	BMC_SPI_DEDI_IO2
3	BMC_SPI_DEDI_CS0	4	+P3V3_SPI_BMC_AUX
5	BMC_SPI_DEDI_MISO	6	BMC_SPI_DEDI_IO3
7	--	8	BMC_SPI_DEDI_CLK
9	GND	10	BMC_SPI_DEDI_MOSI




JCOM1: Console pin header (Pitch 2.0) on board

Pin	Description	Pin	Description
1	BMC_COM2_DCD#	2	BMC_COM2_DSR#
3	BMC_COM2_RX	4	BMC_COM2_DSR#
5	BMC_COM2_TX	6	BMC_COM2_CTS#
7	BMC_COM2_DTR	8	BMC_COM2_RI#
9	GND	10	--




JVGA1: VGA pin header (Pitch 2.0) on board for BMC

Pin	Description	Pin	Description
1	DAC_RO	2	GND
3	DAC_GO	4	GND
5	DAC_BO	6	GND
7	HSYNC_O	8	--
9	VSYNC_O	10	GND
11	DDC_DATA	12	DDC_CLK



JSPI_TPM1: TPM module pin header

Pin	Description	Pin	Description
1	SPI_HD1#	2	SPI_CS1#
3	SPI_CS0#	4	+P3V3_SPI_PCH_AUX
5	SPI_MISO_TPM	6	HEADER_SPI_PCH_IO3
7	--	8	SPI_CLK_TPM
9	GND	10	SPI_MOSI_TPM
11	IRQ_TPM_SPI#_R	12	--
13	SPI_TPM_CS0#	14	RST_PLTRST_PLD_B_N



JBMC_SGPIO1: FPGA programming and debugging

Pin	Description
1	SGPIO_DEBUG_PLD_CLK
2	SGPIO_DEBUG_PLD_DOUT
3	SGPIO_DEBUG_PLD_DIN
4	SGPIO_DEBUG_PLD_LD_N
5	GND



J6:

Pin	Description
1	+P3V3_AUX
2	JTAG_BMC_TDO_CONN
3	JTAG_BMC_TDI_CONN
4	JTAG_BMC_NTRST_N_CONN
5	RST_JTAG_BMC_N
6	JTAG_BMC_TMS_CONN
7	GND
8	JTAG_BMC_TCK_CONN



JIPMB: BMC PSU debug connector

Pin	Description
1	SMB_IPMB_STBY_CMOS_SDA
2	GND
3	SMB_IPMB_STBY_CMOS_SCL
4	+P5V_AUX



JSATAPW1: SATA HDD power pin header

Pin	Description
1	+P12V
2	GND
3	GND
4	+P5V



JBMC_UART5: BMC development debug

Pin	Description
1	+P3V3_AUX
2	BMC_UART5_RX
3	GND
4	BMC_UART5_TX



JRAID_CON1: RAID connector

Pin	Description
1	GND
2	+P3V3_AUX
3	GND
4	FM_PCH_STORAGE_KEY_R



JLCM1: LCM pin header

Pin	Description
1	BMC_LCM_TX
2	BMC_LCM_RX
3	GND
4	+P5V



JPWR1: Power Switch I/O pin header

Pin	Description
1	GND
2	PWRON#



JOPEN1: Case open pin header

Pin	Description
1	FM_INTRUDER#
2	GND



JNMI1: NMI (Non-maskable interrupt) function pin header

Pin	Description
1	GND
2	NMI



JFAN1~12: Fan power pin header

Pin	Description
1	GND
2	+P12V_FAN_SYS
3	BMC_FAN_TECH_IN2
4	BMC_FAN_TECH_IN1
5	+ BMC_PWMOUT

JPSU: Alert Beep

Description
Beep Alert

SW1: Front Panel rest button on board

Description
Front Panel RST button

SW2: Power on button on board

Description
Power ON button

JSATA 1~4


Pin	Description
1	GND
2	TX_P
3	TX_N
4	GND
5	RX_N
6	RX_P
7	GND

JPMBUS1:


Pin	Description
1	SMB_PMBUS_STBY_LVC3_R_SDA
2	GND
3	SMB_PMBUS_STBY_LVC3_R_SCL




JNGFF1



JNGFF2



JNGFF3



Power Connector:


JATX 12~19: 4-pin power connector

Pin	Description	Pin	Description
1	GND	2	GND
3	+P3V3	4	+P12V

JATX3, JATX22: 4-pin power connector

Pin	Description	Pin	Description
1	GND	2	GND
3	GND	4	GND
5	+P12V_GPU	6	+P12V_GPU
7	+P12V_GPU	8	+P12V_GPU

JPCIESL5: I/O Card




Internal Jumpers

The pin headers on the motherboard are often associated with essential functions. With the shunt (Jumper) pushed down on the designated pins (the pin numbers are printed on the circuit board, surrounding the pin header), particular features can be enabled or disabled. While changing the jumpers, make sure your system is turned off.

Jumper Setting

To short the designated pins, push the jumper down on them so that they become **SHORT**. To make the pins setting **OPEN**, simply remove the jumper cap.



JESPI1 (1-2)

1-2 ESPI (Default)

2-3 LPC

Pin	Description
1	--
2	FM_ESPI_EN
3	PD_ESPI_EN



JCPLD_PROV1 (1-2)

1-2 Normal Operation (Default)

2-3 Force PFR CPLD Update

Pin	Description
1	--
2	FM_PFR_PROV_UPDATE_N
3	GND



JCPLD_RCVR1 (1-2)

1-2 Normal Operation (Default)

2-3 Force PFR CPLD Update

Pin	Description
1	--
2	FM_PFR_FORCE_RECOVERY_N
3	GND



JFOR_PWRON1 (1-2)

1-2 Normal Operation (Default)

2-3 Force PFR CPLD Update

Pin	Description
1	--
2	FM_FORCE_PWRON_LVC3
3	+P3V3_AUX



JCPLD_DEB1 (1-2)

1-2 Normal Operation (Default)

2-3 Force PFR CPLD Update

Pin	Description
1	--
2	FM_FORCE_PWRON_LVC3
3	GND



JSMB_PLD_DE1

Pin	Description
1	SMB_DEBUG_PLD_SDA_R
2	GND
3	SMB_DEBUG_PLD_SCL_R



JBMC_HSBP

Pin	Description
1	SMB_HSBP_STBY_LVC3_SCL
2	SMB_HSBP_STBY_LVC3_SDA
3	GND



JBYP0 (2-3)

1-2 Force Bypass of CPU0

2-3 Normal Operation (Default)

Pin	Description
1	--
2	FM_CPU0_SKTOCC_N
3	FM_CPU0_SKTOCC_LVT3_N



JBYP1 (2-3)

1-2 Force Bypass of CPU1

2-3 Normal Operation (Default)

Pin	Description
1	--
2	FM_CPU1_SKTOCC_N
3	FM_CPU1_SKTOCC_LVT3_N



JBMC_REME_DB (2-3)

1-2 Enable BMC Remote Debug

2-3 Disable Remote Debug (Default)

Pin	Description
1	+P3V3_AUX
2	ENABLE BMC REMOTE DEBUG
3	--



JCLRPAS (1-2)

1-2 Normal (Default)

2-3 Password Clear

Pin	Description
1	--
2	FM_PW_CLEAR#
3	GND



JCLRPAS1 (1-2)

1-2 Normal (Default)

2-3 Password Clear

Pin	Description
1	--
2	FM_PW_CLEAR#
3	GND



JMERCVR1 (1-2)

1-2 Normal mode (Default)

2-3 ME Force Update

Pin	Description
1	--
2	FM_ME_RCVR_N
3	GND



JCMOS1 (1-2)

1-2 Normal (Default)

2-3 Clear CMOS

Pin	Description
1	+VRTC
2	PCH_RTCRST#
3	PD_PCH_RTCRST#



JBMC2 (1-2)

1-2 Normal (Default)

2-3 BMC Update

Pin	Description
1	--
2	FM_FORCE_BMC_UPDATE_N
3	PD_FORCE_UPDATE



JPR_MUX1 (2-3)

1-2 T-1Debug

2-3 T0 Debug (Default)

Pin	Description
1	PU_PFR_MUX_SEL
2	FM_PFR_DEBUG_PORT_SEL
3	



J12 (1-2)

1-2 Enable dual BIOS (Default)

2-3 Disable dual BIOS

Pin	Description
1	+P3V3_AUX
2	DUAL_BIOS_DIS
3	GND

J13 (1-2)

1-2 Force Boot up from BIOS1 (Default)

2-3 Force Boot up from BIOS2

Pin	Description
1	+P3V3_AUX
2	BIOS_BOOT_SEL
3	GND




JDUAL1 (1-2, 3-4)

1-2, 3-4 Flash 1st BIOS (Default)

1-3, 2-4 Flash 2nd BIOS

Pin	Description
1	SPI_CS0#
2	SPI_PCH_MUXED_CS0_N
3	SPI_PCH_MUXED_CS1_N
4	SPI_CS1#



JRST1: Reset (2-3)

Controls the software rest method of the Reset button on the front panel

1-2 Hardware Reset

2-3 Software Reset (Default)

JLPC/ESPI1 (1-2)

1-2 CS0# To BMC (Default)

2-3 CS0# To LPC/ESPI CONN

JBMCDBG (1-2)

1-2 SPD Remote Debug Disabled (Default)


2-3 SPD Remote Debug Enabled

CHAPTER 3: HARDWARE SETUP


To reduce the risk of personal injury, electric shock, or damage to the system, please remove all power connections to completely shut down the device. Also, please wear ESD protection gloves when conducting the steps in this chapter.

Opening the Chassis

1. Loosen the 2 thumb screws from the rear panel of NCA-6520.
2. Gently pull the cover backward a bit.
3. Lift the cover up to remove it.



4. Unscrew the twelve (12) screws securing the cover/hood that protects the CPUs and the fans.
5. Lift up the cover/hood and place it aside. Please follow the instructions below to install the processor and heatsink module.



Installing the CPU

Please note that the system delivered to you includes the heatsink and processor. This processor comes with a rather sophisticated design, therefore, the assembly of which must be handled with exclusive tools and extreme care by professionals. Please read through the instructions in this section and refer to the [official tutorial](#) released by Intel® to make sure you have acquired the necessary knowledge and comply with the requirements.

Installing the processor onto the motherboard involves two stages:


1. Mount the processor onto the heat sink to make a PHM (Processor + Heat Sink Module)
2. Install the PHM onto the motherboard.




Tools Required

Tool	Description	
(T-30 Torx Bit®)	Set to <u>8in/lb</u> for tightening the nuts which fasten the PHM on the bolster plate.	
ESD Protection (ESD gloves, ESD-safe work surface, ESD-safe shoes, grounded wrist strap etc.)	During the entire assembly process, at least wear a pair of ESD gloves to avoid damaging or contaminating the electronic parts while enhancing your own safety.	

Note: The images of tools shown in this document are merely for reference; the actual tools you use might differ.


Parts Explanation:

Item	Description	
Processor	Please avoid touching the gold fingers or package lands of the processor even if you are wearing ESD gloves.	 


<p>Heat Sink</p>	<p>If a TIM (Thermal Interface Material) protective film is already attached to the base of the heat sink, remove it before you mount the processor on it.</p> <p>When holding the heatsink, please grip it along the axis of its fins with your thumb and your index finger.</p>	
<p>Processor Carrier</p>	<p>This is packed along with the processor. Before performing any assembly involving this part, please locate PIN1 on one of the corners, an important indicator used to align this carrier with the processor and the bolster plate correctly.</p>	
<p>Socket Cover</p>	<p>This cover is used to protect the package land surface of the processor from contamination. To remove it from the processor, grasp the holding features with your thumb and your index finger while pulling the cover off vertically.</p>	
<p>Bolster Plate</p>	<p>A robust bolster plate is used to assist in PHM alignment for installation, while effectively helping eliminate PCB bowing during compression. Please locate the Cutout on one of the four corners before starting PHM installation.</p>	

Mounting the CPU onto the Heat Sink


1. With the processor in the shipping tray, align the **PIN1** indicator on the processor carrier to the **PIN1** marking on the processor.



2. And line up the two keying features on the processor carrier.




3. Gently press on the each of the press tabs at the top and bottom of the carrier to engage the locking tabs




Note: During assembly, it is essential to have (1) PIN1 on the processor carrier aligned with the processor, and (2) the alignment features on the top and the bottom of the processor aligned with the corresponding carrier latches.


4. Push down on the two sides to engage the side locking tabs. Check to make sure all four locking tabs have been attached to the processor.




5. Align **PIN1** of the heatsink to the PIN1 indicator of the processor carrier (if there are two corner cutouts on one heat sink, either will do).



6. Lower the PIN1 end of the heatsink over the processor carrier to engage the two locking tabs near the corners. Then push the other end down to engage the locking tabs at the remaining corners. You might hear a clicking sound when the latch clicks into place. There should not be any gaps between the heatsink and the carrier.




7. The PHM is now ready to be integrated into the socket.




Installing the PHM onto the Motherboard

1. Remove the socket cover from the socket contacts of the motherboard by grasping the tabs on either side. Squeeze inward


Note: Inspect the surface of the socket under sufficient lighting to ensure there is no contamination or damage prior to the PHM installation.




2. Set each anti-tilt wire to inward or unlocked position on the heatsink.




3. Lift up the PHM. Turn the PHM over to locate the **PIN1** corner on processor carrier and processor.




4. Then turn the PHM right side up. Line up the **PIN1** corner of the PHM to the bolster plate **PIN1** corner. Lower the PHM vertically down over the bolster plate studs.




5. Move each anti-tilt wire to outward or locked position.



6. Check the anti-tilt wires are in locked position and have engaged the anti-tilt flanges on the bolster plate.




7. Use a torque driver with a T-30 Torx bit to tighten the four nuts to 8 in/lb in the bolster plate.



Installing the System Memory

The motherboard supports DDR4 registered DIMM memory for heavy-duty operations. Please follow the steps below to install the DIMM memory modules. The primary CPU and the secondary CPU both have 12 DIMM sockets (6 on each side)





- Supported Capacities: 8/16/32/64 GB
- Maximum RAM: **1536GB** (64GB per slot)

DIMM Population Guidelines:

Please do follow the memory module installation instructions to install the DIMM, and make sure the DIMM population guidelines are met:

- Each CPU requires at least 1 memory module to boot and run from.
- If you do not plan to fill up all the sockets with 24 memory modules, always start with the blue ones for optimal performance.
- Try to split the DIMMs evenly across the CPUs.
- Please use memory modules of the same capacity, speed and from the same manufacturer to avoid compatibility issues.





DIMM Population Notes:

- 1 DIMM: validated on any slot
- 2 DIMM: validated AE, CG, AC, EG, & AD⁴
- >2 DIMMs: Channel population can be different than shown as long as symmetric left/Right across the socket.
- >2 DIMMs: Configs with channel 0 populated before channel 1 on each MC are validated configs⁴
- A/E/C/G channels must be populated with same total capacity per channel if populate
- B/F/D/H channels must be populated with same total capacity if populated¹
- SNC2 configuration requires full asymmetry together with LEFT/RIGHT symmetry

¹ – If capacity requirement not followed, all memory may not be mapped

² – Rank sparing, ADDDC, channel mirroring, Hemi, and 2LM not supported with SGX


³ – 6 way Interleave requires same channel capacity on all 6 channels

⁴ – AD & ADEH additionally validated to allow for 2 different DIMM sizes in 2&4 DIMM configs


Memory Module Installation Instructions

Please follow the steps below to install the DIMM memory modules.


1. Power off the system.
2. Pull open the DIMM slot latches.



3. Align the notch of the DIMM module with the socket key in the slot.





4. Insert the module into the slot until it is firmly seated. The motherboard of NCA-6520 is designed with 20 DDR DIMM sockets.



Installing TPM Module (Optional)

The motherboard provides one TPM slot. Follow the procedures below for installing a TPM module.

1. Locate the TPM pin on the motherboard.



2. Insert the module into the TPM pins until it is fully seated.




Installing the Riser Converter Card (Optional)

The motherboard provides two M.2 slots. Follow the procedures below for installing a M.2 riser converter card.


1. The Riser card kit includes:

- ▶ 1x Converter Card
- ▶ 1x Connector cable
- ▶ 1x screw




2. Power off the system.

3. Locate the M.2 slot on the motherboard.



4. Align the notch of the U.2 converter card with the socket key in the pin slot.




5. Insert the U.2 converter card pins at 30 degrees into the socket until it is fully seated.





6. Push down on the module and secure it with a screw.



7. Insert one end of the connector cable to the converter card.



8. Connect the other end of the cable to the HDD/SSD backplane. Follow the procedures below for installing the SSD drive.




Installing the Disk Drive(s) (Optional)

NCA-6520 is built with two 3.5" HDD/SSD slot (HDD preferred) drive bay. The following will discuss disk drive installation procedures based on their HDD/SSD designs.

1. Power off the system.
2. Locate the 3.5" disk bay on the front panel.




3. To remove the tray, put your finger on the tab and push it to the left to slide it open, hold the tab lever and pull out the tray.



4. The tray is designed to accommodate one 3.5" hard disk or one 2.5" hard disk.


Mounting a 3.5" hard disk

Secure the hard disk on the tray with the provided disk screws. Make sure the disk SATA connector faces towards the SATA contacts inside the system.




Mounting a 2.5" hard disk

Secure the hard disk on the tray with the provided disk screws. Make sure the disk SATA connector faces towards the SATA connector inside the system.




5. To install the mounted disk tray, push the tray into position in the chassis. Press the hinge tab until it clicks into place.



Installing the NIC Modules (Optional)

NCA-6520 comes with 8 NIC Ethernet module slots for network bandwidth expansion. Please follow the steps for installation.


1. On the front panel, select a NIC Ethernet module slot.




2. Rotate clockwise and loosen the two lock-screws.




3. Remove the door and locate the PCIe socket for module insertion.



4. Insert your NIC Ethernet module.
(The module shown in the image below is for reference only).



Align the golden fingers to the PCIe socket on the motherboard carefully while inserting this module.



5. Once the module is firmly seated, rotate counter-clockwise and tighten the two lock-screws.



Installing the LCM Module (Optional)

NCA-6520 comes with module slots for LCM module expansion. Please follow the steps for installation.


1. The LCM module package will

include:


- ▶ 1x LCM Panel
- ▶ 1x LCM connector cable
- ▶ 2x screws




2. On the front panel of NCA-6520, select the upper first module slot for LCM Module placement.



3. Loosen the two lock-screws and remove the door.





4. Locate the connector for LCM module cable insertion.



5. Install the LCM module into the module slot.





6. Insert the connector cable into the connector.
7. Rotate and screw in the two lock screws. The LCM module has been successfully installed.




Installing the M.2 SSD memory card (Optional)

NCA-6520 comes with an additional M.2 SSD memory card slot. Please follow the steps for installation.

1. Power off the system.
2. Locate the M.2 slot on the motherboard.



3. Align the notch of the M.2 memory card with the socket key in the pin slot.



4. Insert the M.2 memory card pins at 30 degrees into the socket until it is fully seated.




5. Push down on the module and secure it with a screw.




Installing the GPU graphic card (Optional)

NCA-6520 comes with optional slots for GPU graphic card expansion. The GPU graphic card requires a rather complex installation process; therefore, the assembly must be handled with care. Please read through the instructions in this section and refer to the [tutorial video](#) to make sure you have acquired the necessary knowledge and comply with the requirements.

1. The GPU expansion kit will include:
 - ▶ 1x PCIe bracket (right-side or left-side)
 - ▶ 1x or 2x Swappable fan(s)
 - ▶ 1x GPU module
 - ▶ 1x GPU power cable
 - ▶ Xx screws




2. Power off the system and open the top cover. Unscrew and remove the black cover/hood (pls refer to p.28). Remove the original PCIe bracket (right-side or left-side).




3. Unscrew two (2) screws to remove the original PCIe bracket.



4. Pick up the new PCIe bracket, and assemble the fan(s) first. Slide the fan towards the end of the bracket, and slip the fan power cable through the holes indicated.



5. Secure the fan module with three (3) screws on each fan and one (1) screw on the side. Repeat the same assemble process with the second fan.




6. Turn the bracket to the other end, align the GPU card module to the PCIe bracket. Slide the GPU module into the PCIe bracket until it is completely seated and clicks.



7. Place the side panel in place, and screw in four (4) screws.




8. Locate the fan cable connector.




9. Insert the fan power cables into the connector.

10. Then, mount the PCIe bracket with the installed GPU card module in the slot.




11. Secure the PCIe bracket to the system with five (5) screws.



12. Connect the PCIe cable to the golden fingers until it is fully seated and secure with two (2) screws.




13. Insert the GPU power cable to the side of the GPU module. Other end of power cable should have been pre-installed on the motherboard. The GPU module installation has been completed.



NFVI Platform Configure Installation (Optional)

This section is on configuring the system to support NFVI optimal platform. In order to increase Intel® QuickAssist Technology (QAT) performance, a slimSAS cable (straight-to-straight) can link the Platform Control Hub (PCH) to CPU1 directly, and eliminates the need to pass through CPU0 before reaching CPU1. Please follow the steps for installation.

1. Power off the system and open the top cover.
2. Locate U148 and U149 connector on the motherboard.



3. Link the U148 connector to the U149 connector with the QAT cable.




Replacing the Cooling Fans

Cooling fans may wear down eventually. Please refer to the steps below for replacing cooling fans. When using a new cooling fan, simply reverse the steps to install the fan back onto the enclosure and the system.


1. Make sure to have 1x screwdriver, and 1x 5mm socket screwdriver (Hex nut screwdriver). Locate the cooling fans at the rear panel.




2. Loosen the (one) lock-screw of the fan you would like to replace.




3. Hold onto the lock-screw and pull out the single fan.




4. Remove the 4 screws that secure the fan.



5. Remove the two (2) screws securing top fan connector.



6. Use the 5mm socket screwdriver to remove the two (2) hex column screw nuts securing the bottom fan connector.



7. Take the fan and fan connectors out of the enclosure. The fan connectors will be connected to the motherboard, to remove, disconnect from the motherboard.




8. When using a new cooling fan, simply reverse the steps to install the fan back onto the enclosure and the system.


Replacing the Power Supply Units

Power supply units may wear down eventually. Please be noted that NCA-6520 series supports 1300W/2000W depending on the ordering preferences. Please prepare the power supply units matching this capacity.

1. On the rear panel, locate the power supply unit(s) and disconnect the power cords.




2. Pull the system out. (Pls note the images here are for reference only.)



3. Locate the internal connector of the power supply unit.

Power supply connector




4. Insert a new power supply unit. Push the unit in until it clicks into place.



Mounting the System


The system can be installed in a rack using the Slide Rail Kit plus Short Mounting Ear brackets (optional). This method is rather complicated, but the slidable rails allow you to access the system easily while solidly securing the system in the rack. Please follow the steps below for installation.




The Slide Rail Kit can secure the system while providing sufficient weight support for the device.

1. Check the package contents of the Slide Rail Kit. The kit shall include the following items:

- ▶ 1x pack of M4X4L screws (for securing the sliding rail on the system)
- ▶ 1x pack of 7.1mm Round Hole screws (for securing the system on the rail posts)
- ▶ 2x Slide Rails




The rail consists of the following parts:




Attaching the Rail Brackets


2. Unpack a slide rail and slide the inner channel all the way to the end.




3. Remove the bracket from the Inner Rail by pushing the Release Tab on the bracket outwards while sliding it out. Stretch the bracket to the fullest.



4. Align the bracket to the side of the chassis and make sure the screw-holes are matched, and then secure the bracket onto the chassis with five provided M4X4L screws.




5. Repeat Steps 2~5 to attach the bracket to the other side of the chassis.




Assembling the Ear Brackets

1. Check the package contents. The supplied mounting kit shall include the items below:

- ▶ 1x pack of screws
- ▶ 2x Standard Ear Brackets




2. Install the brackets on both sides of the system using the provided screws.




Installing the Slide Rails

Next, you shall install the slide rail assemblies onto the rack.

1. This slide-rail kit does NOT require screw-fixing. Simply aim at three (3) available screw holes on the rack front and snap the rail front into the rack post as shown in the image below. You should hear a "click" sound once it is firmly attached.




2. For the rear rack installation, slide the rail to aim and engage the bolts on the rail's rear end with the 2 available holes on the post, and the rail assembly will click into place.




Installing the System into the Rack


1. Stretch both of the inner rails out to their fullest extent. You will hear a click sound when they are fully stretched and locked.




2. Hold the system with its front facing you, lift the chassis and gently engage the brackets on the model while aligning them with the slide-rail assemblies as shown in the image below, and then push the system into the cabinet.



3. While pushing in the system, please also push and hold the Rail Lock tab on both brackets.



The system has completed installation in the rack.



Removing the System from the Rack


1. To remove the system from the rack, gently pull it outwards towards you while pushing the Release Tab on both sides of the brackets.



Install DC Power Supply

The NCA-6520 series supports 1600W, depending on the ordering preferences. Please prepare the power supply units matching this capacity.

1. Connect the power cord to the connector.



- This product is intended to be supplied by a UL Listed DC power source, rated 46-72V, 40A minimum, Tma= 40 degrees C, and the altitude of operation=2000 m. If you need further assistance with purchasing the power source, please contact Lanner Electronics Inc. for further information.
- The cable should be 10AWG (20A minimum, -60V minimum).
- Use at least a 20-amp fuse for each DC breaker.
- The power supply shall not exceed 90A peak inrush current requirements for initial startup condition within the rated DC input voltage.

CHAPTER 4: REMOTE SERVER MANAGEMENT

Overview

This chapter will introduce the features of Lanner’s BMC firmware and how to perform server remote management through it. Lanner has implemented IPMI 2.0 based on ASPEED service processor, performing all the BMC defined by IPMI 2.0. In addition, Lanner’s BMC firmware runs an embedded web-server for full configuration using Web UI, which has a low learning curve.

BMC Main Features

	Feature	Description
IPMI 2.0 Standard Features	System Interface Support	<ul style="list-style-type: none"> • KCS (System Interface Support) • LAN (RMCP+)
	IPMI 2.0 based Management	<ul style="list-style-type: none"> • BMC stack with an IPMI 2.0 implementation
	System Management	<ul style="list-style-type: none"> • Sensor monitoring • System power management • Watchdog timer • Fan speed monitor and control • FRU information
	Event Log	<ul style="list-style-type: none"> • System Event Log (SEL)
	Text Console Redirection: SOL	<ul style="list-style-type: none"> • Support in IPMI stack for SOL to remotely access BIOS and text console before OS booting
	User Management	<ul style="list-style-type: none"> • IPMI based user management • Multiple user permission level
Non-IPMI Functions	Web User Interfaces	<ul style="list-style-type: none"> • BMC management via web user interface • Integrated KVM and Virtual Media • TLS 1.2 and TLS 1.3 support
	User Authorization	<ul style="list-style-type: none"> • RADIUS support • LDAP support
	Security	<ul style="list-style-type: none"> • SSL and HTTPS support
	Maintenance	<ul style="list-style-type: none"> • Auto-sync time with NTP server • Remote firmware update by Web UI or Linux tool
	SNMP v3 Access	<ul style="list-style-type: none"> • SNMP walk to get BMC info • SNMP set to control system power status

BMC Firmware Functional Description

System health monitoring

The BMC implements system sensor monitoring feature. It could monitor voltage, temperature, and current of critical components.

System Power Management

The BMC implements chassis power and resets functions for system administrators to control and manage the system power behavior. These functions can be activated by sending the IPMI 2.0 compatible chassis commands to the BMC over messaging interfaces. The following list summarizes the supported functions.

- Chassis power on
- Chassis power off
- Chassis power cycle
- Chassis power reset
- Chassis power soft
- Server's power status report

Watchdog Timer

The BMC provides an IPMI 2.0 compatible watchdog timer which can prevent the system from system hanging.

Fan Speed Control

BMC oversees fan speed control. The fan speed can be modified by varying the duty cycle of PWM signal. The fan speed control algorithm mainly refers to the readings of on-board temperature sensors.

Field Replaceable Unit (FRU)

The BMC implements an interface for logical FRU inventory devices as specified in IPMI 2.0 specification. This functionality provides commands for system administrators to access and management the FRU inventory information.

System Event Log (SEL)

A non-volatile storage space is allocated to store system events for system status tracking.

Serial over LAN (SOL)

IPMI 2.0 SOL is implemented to redirect the system serial controller traffic over an IPMI session. System administrators are able to establish a SOL connection with a standard IPMI client, like IPMITOOL, to remotely interact with serial text-based interfaces such as OS command-line and serial redirected BIOS interfaces.

User Management

The BMC supports 9 IDs for IPMI user accounts. The maximum length of the username and password are 16 and 20 respectively, and the possible privilege levels are Callback, User, Operator, and Administrator. Moreover, the account creator can enable/disable the user account at any time. If not specified, the default user accounts are listed follows:

User Name	Password	User Access	Characteristics
admin	admin	Enabled	Password can be changed

Keyboard, Video, Mouse (KVM) Redirection

- The BMC provides keyboard, video, and mouse (KVM) redirection over LAN. This application is available remotely from the embedded web server.
- Support video recording, recorded videos to be downloaded & playable.

Virtual Media Redirection

- The BMC provides remote virtual CD, HD and FD redirection. CD image could be mounted directly in KVM window. HD, FD could be mounted by NFS and SAMBA.
- Efficient USB 2.0 based CD/DVD redirection with a typical speed of 20XCD.
- Completely secured transmission.

SNMP v3 Access

The BMC provides SNMP v3 accessibility, user could use the SNMP after setup the related setting on the User List page. The following are some SNMP command examples.

1.3.6.1.4.1.51188.2.1.1 (Get Sensor Info, column-1: index, column-2: name, column-3: number, column-4: reading)

1.3.6.1.4.1.51188.1.1.0 (Get/Set Hostname)

1.3.6.1.4.1.51188.1.2.0 (Get BMC Version)

1.3.6.1.4.1.51188.1.3.0 (Get System Power Status, 0 for off, 1 for on)

1.3.6.1.4.1.51188.1.4.0 (System Power Control, 1 for off, 2 for on, 3 for cycle, 4 for soft-off)

IPMI Commands Support List

COMMANDS	NETFN	CMD
IPM Device "Global" Commands		
Get Device ID	APP (06h)	00h
Cold Reset	APP (06h)	02h
Warm Reset	APP (06h)	03h
Get Device GUID	APP (06h)	08h
BMC Watchdog Timer Commands		
Reset Watchdog Timer	APP (06h)	22h
Set Watchdog Timer	APP (06h)	24h
Get Watchdog Timer	APP (06h)	25h
BMC Device and Messaging Commands		
Get System GUID	APP (06h)	37h
Get Channel Info	APP (06h)	42h
Set User Access	APP (06h)	43h
Get User Access	APP (06h)	44h
Set User Name	APP (06h)	45h
Get User Name	APP (06h)	46h
Set User Password	APP (06h)	47h
Chassis Device Commands		
Get Chassis Capabilities	Chassis (00h)	00h
Get Chassis Status	Chassis (00h)	01h
Chassis Control	Chassis (00h)	02h
Chassis Reset	Chassis (00h)	03h
Sensor Device Commands		
Get Sensor Reading Factors	S/E (04h)	23h
Get Sensor Hysteresis	S/E (04h)	25h
Get Sensor Threshold	S/E (04h)	27h
Get Sensor Event Enable	S/E (04h)	29h
Get Sensor Event Status	S/E (04h)	2Bh
Get Sensor Reading	S/E (04h)	2Dh
Get Sensor Type	S/E (04h)	2Fh
FRU Device Commands		
Get FRU Inventory Area Info	Storage (0Ah)	10h
Read FRU Data	Storage (0Ah)	11h
Write FRU Data	Storage (0Ah)	12h
SDR Device Commands		
Get SDR Repository Info	Storage (0Ah)	20h
Get SDR Repository Allocation Info	Storage (0Ah)	21h
Get SDR	Storage (0Ah)	23h
Get SDR Repository Time	Storage (0Ah)	28h
SEL Device Commands		
Get SEL Info	Storage (0Ah)	40h
Get SEL Allocation Info	Storage (0Ah)	41h


Get SEL Entry	Storage (0Ah)	43h
Delete SEL Entry	Storage (0Ah)	46h
Clear SEL	Storage (0Ah)	47h
Get SEL Time	Storage (0Ah)	48h
Set SEL Time	Storage (0Ah)	49h
Get SEL Time UTC Offset	Storage (0Ah)	5Ch
Set SEL Time UTC Offset	Storage (0Ah)	5Dh
LAN Device Commands		
Set LAN Configuration Parameters	Transport (0Ch)	01h
Get LAN Configuration Parameters	Transport (0Ch)	02h
Serial/Modem Device Commands		
Set User Callback Options	Transport (0Ch)	1Ah
Get User Callback Options	Transport (0Ch)	1Bh
SOL Activating	Transport (0Ch)	20h
Set SOL Configuration Parameters	Transport (0Ch)	21h
Get SOL Configuration Parameters	Transport (0Ch)	22h

Using BMC Web UI

In the address bar of your Internet browser, input the IP address of the remote server to access the BMC interface of that server.



Initial access of BMC prompts you to enter the User Name and Password. A screenshot of the login screen is given below:



Login Page

- ▶ **Username:** Enter your username in this field.
- ▶ **Password:** Enter your password in this field.
- ▶ **Sign me in:** After entering the required credentials, click the **Sign me in** to log in to Web UI.




Note: (1) If not specified, the default IP to access BMC is <https://192.168.0.100>.
(2) Please use **https** to access Web UI.

Default User Name and Password


- ▶ **Username:** admin
- ▶ **Password:** admin

The default username and password are in lower-case characters. When you log in using the default username and password, you will get full administrative rights, and it will ask you to change the default password once you log in. The dialog is shown below:



Change the default password - Dialog

Clicking on **OK** will bring you to the User Management Configuration page to set a password.



Change the default password – Set password



Note: Duplicate usernames shouldn't exist across different authentication methods like LDAP, RADIUS or IPMI, since the privilege of one Authentication method is overwritten by another authentication method during logging in, and hence the correct privilege cannot be returned properly.


First Time Wizard Welcome Page Introduction

After the first-time login, you will see first time wizard welcome page as the following picture. Please press the "Next" button and configure your BMC step by step.

On the "IPv4", "IPv6" and "DNS" pages, you could specify the hostname and network settings of BMC.

On the "Remote Control" page, you could specify allowed IP region which could access KVM and Remote media web pages.

On the "Date and Time" page, you could specify the NTP and time settings.




In the final page, please press "Finish" button to complete the first-time wizard. BMC will be rebooted and apply new settings. You could reconnect to the WebUI after a few minutes.

Web UI Layout Introduction

The BMC Web UI consists of various menu items:

Menu Bar

A screenshot of the menu bar is shown below, please select the page you would like to navigate.



Menu Bar

Quick Button and Logged-in User


The user information and quick buttons are located at the top right of the Web UI.



User Information



Logged-in user information: Click the icon  to view the logged-in user information.

A screenshot of the logged-in user information is shown below:



Logged-in User Information

The logged-in user information shows the logged-in user's username, user privilege, with the quick buttons allowing you to perform the following functions:

- ▶ **Refresh:** Click the icon  to reload the current page.
- ▶ **Sign out:** Click the icon  to log out of the Web UI.

Logged-in user and its privilege level

This option shows the logged-in username and privilege. There are four kinds of privileges:

- ▶ **User:** Only valid commands are allowed.
- ▶ **Operator:** All BMC commands are allowed except for the configuration commands that can change the behavior of the out-of-hand interfaces.
- ▶ **Administrator:** All BMC commands are allowed.
- ▶ **No Access:** Login access denied.

Help

Help: The **Help** icon  is located at the top right of each page in Web UI. Click this help icon to view more detailed field descriptions.

CHAPTER 5: BIOS SETUP

The system has AMI BIOS built-in, with a SETUP utility that allows users to configure required settings or to activate certain system features. Pressing the <Tab> or key immediately allows you to enter the Setup Utility.

Enter BIOS Setup


To enter the BIOS setup utility, simply follow the steps below:

1. Boot up the system.
2. Press <Delete> during the boot-up if you connect a keyboard to this unit. But if you connect a PC to this unit through console USB/Serial connection, then press <Tab>. Your system should be running POST (Power-On-Self-Test) upon booting up.
3. Then you will be directed to the BIOS main screen.
4. Instructions of BIOS navigations:

Control Keys	Description
→←	select a setup screen, for instance, [Main], [Advanced], [Platform], [Socket], [Server Mgmt], [Security], [Boot], and [Save & Exit]
↑↓	select an item/option on a setup screen
<Enter>	select an item/option or enter a sub-menu
+/-	to adjust values for the selected setup item/option
F1	to display General Help screen
F2	to retrieve previous values, such as the parameters configured the last time you had entered BIOS.
F3	to load optimized default values
F4	to save configurations and exit BIOS
<Esc>	exit the current screen

Main Page

Setup Main Page contains BIOS information and project version information.




(The screenshots presented in this section are for reference only)

Item	Description
BIOS Information	BIOS Vendor: American Megatrends Core Version: AMI Kernel version, CRB code base, X64 Compliance : UEFI version, PI version Project Version: BIOS release version Build Date and Time: MM/DD/YYYY Access Level: Administrator / User
Memory Information	Total Memory: by case
System Date	To set the Date, use <Tab> to switch between Date elements. Default range of Year: 2005-2099 Default range of Month: 1-12 Days: dependent on Month.
System Time	To set the Date, use <Tab> to switch between Date elements.


Advanced Setup

Select the Advanced menu tab from the BIOS setup screen to enter the “Advanced” setup screen. Users can select any of the items in the left frame of the screen.




Trusted Computing

This option allows you to configure parameters regarding BIOS support for security device. Press <Enter> to access the submenu.



Feature	Options	Description
Security Device Support	Enabled Disabled	Enables or disables BIOS support for security device. By disabling this function, OS will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

Trusted Computing (TPM1.2)



Item	Option	Description
Security Device Support	Enabled Disabled	Enables or disables BIOS support for the security device. By disabling this function, OS will not show Security Device. TCG EFI protocol and INT1A interface will not be available.
TPM State	Enabled Disabled	Enables or disables Security Device. NOTE: Your computer will reboot during a restart in order to change State of the Device.
Pending operation	None TPM Clear	Schedules an Operation for the Security Device. NOTE: Your computer will reboot during a restart in order to change State of Security Device.
Device Select	TPM 1.2 TPM 2.0 Auto	TPM 1.2 will restrict support to TPM 1.2 devices; while TPM 2.0 will restrict support to TPM 2.0 devices; Auto will support both with the default set to TPM 2.0 devices. If not found, TPM 1.2 devices will be enumerated.

Trusted Computing (TPM 2.0)

Aptio Setup Utility - Copyright (C) 2017 American Megatrends, Inc.

Advanced

TPM20 Device Found		▲ Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.
Vendor: NTC		
Firmware Version: 1.3		
Security Device Support	[Enable]	
Active PCR banks	SHA-1,SHA256	
Available PCR banks	SHA-1,SHA256	
SHA-1 PCR Bank	[Enabled]	▲: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
SHA256 PCR Bank	[Enabled]	
Pending operation	[None]	
Platform Hierarchy	[Enabled]	
Storage Hierarchy	[Enabled]	
Endorsement Hierarchy	[Enabled]	

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc. AB

Aptio Setup Utility - Copyright (C) 2017 American Megatrends, Inc.

Advanced

Active PCR banks	SHA-1,SHA256	▲ TPM 1.2 will restrict support to TPM 1.2 devices, TPM 2.0 will restrict support to TPM 2.0 devices, Auto will support both with the default set to TPM 2.0 devices if not found,
Available PCR banks	SHA-1,SHA256	
SHA-1 PCR Bank	[Enabled]	▲: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
SHA256 PCR Bank	[Enabled]	
Pending operation	[None]	
Platform Hierarchy	[Enabled]	
Storage Hierarchy	[Enabled]	
Endorsement Hierarchy	[Enabled]	
TPM2.0 UEFI Spec	[TCG_2]	
Version		
Physical Presence Spec Version	[1.3]	
TPM 20 InterfaceType	[TIS]	
Device Select	[Auto]	

Version 2.19.1268. Copyright (C) 2017 American Megatrends, Inc. AB

Item	Option	Description
Security Device Support	Enabled Disabled	Enables or disables BIOS support for security device. By disabling this function, OS will not show Security Device. TCG EFI protocol and INT1A interface will not be available.
SHA-1 PCR Bank	Enabled Disabled	Enables or disables SHA-1 PCR Bank.
SHA256 PCR Bank	Enabled Disabled	Enables or disables SHA256 PCR Bank.
Pending operation	None TPM Clear	Schedules an Operation for the Security Device. NOTE: Your computer will reboot during restart in order to change State of Security Device.
Platform Hierarchy	Enabled Disabled	Enables or disables Platform Hierarchy.
Storage Hierarchy	Enabled Disabled	Enables or disables Storage Hierarchy.
Endorsement Hierarchy	Enabled Disabled	Enables or disables Endorsement Hierarchy.
TPM2.0 UEFI Spec Version	TCG_1_2 TCG_2	Select the TCG2 Spec Version, TCG_1_2: Supports the Compatible mode for Win8/Win10 TCG_2: Supports new TCG2 protocol and event format for Win10 or later.
Physical Presence Spec Version	1.2 1.3	Select to tell OS to support PPI Spec Version 1.2 or 1.3. NOTE: Some HCK tests might not support 1.3.
TPM 20 Interface Type	TIS	Select TPM 20 Device for the Communication Interface.
Device Select	TPM 1.2 TPM 2.0 Auto	TPM 1.2 will restrict support to TPM 1.2 devices; while TPM 2.0 will restrict support to TPM 2.0 devices; Auto will support both with the default set to TPM 2.0 devices. If not found, TPM 1.2 devices will be enumerated.


Super IO Configuration

This option allows you to configure parameters about Super IO Chip. Press **<Enter>** to access the submenu.




Serial Port 1 Configuration

Select "Serial Port 1 Configuration" or "Serial Port 2 Configuration" to enter sub setting screen.



Item	Option	Description
Serial Port	Enabled Disabled	Enables or disables Serial Port 1.
Device Settings	NA	IO=3F8h; IRQ = 4


Serial Port 2 Configuration



Item	Option	Description
Serial Port	Enabled Disabled	Enables or disables Serial Port 2
Device Settings	NA	IO=2F8h; IRQ = 3

Digital IO Configuration

This option allows you to configure parameters about Digital IO pins.



Item	Option	Description
Digital I/O Output 1	Output High Output Low	Configure Digital I/O Pin5
Digital I/O Output 2	Output High Output Low	Configure Digital I/O Pin6
Digital I/O Output 3	Output High Output Low	Configure Digital I/O Pin7
Digital I/O Output 4	Output High Output Low	Configure Digital I/O Pin8

Status LED Configuration


This option allows you to change the color of status LED.



Item	Option	Description
Status LED	OFF GREEN RED	Configures Status LED color

Watch Dog Timer Configuration


This option allows you to enable or disable the watchdog timer function.



Item	Option	Description
Watch Dog Timer	Enabled Disabled	Enables or disables Watch Dog Timer function

Serial Port Console Redirection


This option allows you to configure parameters about serial port console redirection. Press <Enter> to access the submenu.



Item	Option	Description
COM0 Console Redirection	Enabled Disabled	Enables or disables Console Redirection

Console Redirection Settings

These settings specify how the host computer and the remote computer will exchange data. Both computers should have the same or compatible settings.




Item	Option	Description
Terminal Type	VT100	VT100: ASCII char set
	VT100+	VT100+: Extends VT100 to support color, function keys, etc.
	VT-UTF8	VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes
	ANSI	ANSI: Extended ASCII char set
Bits per second	9600	Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
	19200	
	38400	
	57600	
	115200	
Data Bits	7	Data Bits
	8	
Parity	None	A parity bit can be sent with the data bits to detect some transmission errors.
	Even	
	Odd	
	Mark Space	

Stop Bits	1 2	Indicates the end of a serial data packet.
Flow Control	None Hardware RTS/CTS	Flow Control can prevent data loss from buffer overflow.
VT-UTF8 Combo Key Support	Disabled Enabled	Enables VT-UTF8 Combination Key Support for ANSI/VT100 terminals
Recorder Mode	Disabled Enabled	With this mode enabled, only text will be sent. This is to capture Terminal data.
Resolution 100x31	Disabled Enabled	Enables or disables extended terminal resolution
Putty KeyPad	VT100 LINUX XTERM86 SCO ESCN VT400	Selects FunctionKey and KeyPad on Putty.

Legacy Console Redirection Settings


This option allows you to configure legacy console redirection options. Press **<Enter>** to access the submenu.



Item	Option	Description
Legacy Serial Redirection Port	COM0	Select a COM port to display redirection of Legacy OS and Legacy OPRM Messages
Legacy OS Redirection Resolution	80x24 80x25	On Legacy OS, the Number of Rows and Columns supported redirection.
Redirection After BIOS POST	Always Enable Boot Loader	When Bootloader is selected, legacy Console Redirection is disabled before booting to legacy OS. When Always Enable is selected, then Legacy Console Redirection is enabled for legacy OS. Default setting for this option is set to Always Enable .

PCI Subsystem Settings


This option allows you to change the PCI, PCI-X and PCI Express settings.



Item	Option	Description
Above 4G Decoding	Disabled Enabled	Enables or disables 64bit capable Devices to be Decoded in Above 4G Address Space (Only if System Supports 64-bit PCI Decoding)
SR-IOV Support	Disabled Enabled	If the system has SR-IOV capable PCIe Devices, this option enables or disables Single Root IO Virtualization Support.

USB Configuration


This option allows you to change USB configuration parameters.



Item	Option	Description
Legacy USB Support	Enabled Disabled Auto	Enables Legacy USB support. Auto option disables legacy support if no USB devices are connected; Disabled option will keep USB devices available only for EFI applications.
XHCI Hand-off	Enabled Disabled	This is a workaround for OSES without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
USB Mass Storage Driver Support	Enabled Disabled	Enables or disables USB Mass Storage Driver Support.
USB transfer time-out	1 sec 5 sec 10 sec 20 sec	The time-out value for Control, Bulk, and Interrupt transfers
Device reset time-out	1 sec 5 sec 10 sec 20 sec	USB mass storage device Start Unit command time-out
Device power-up delay	Auto Manual	Maximum time the device will take before it properly reports itself to the Host Controller. Auto uses default value: for a Root port, it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

Network Stack Configuration


This option enables or disables UEFI network stack.



Item	Option	Description
Network Stack	Disabled Enabled	Enables or disables UEFI Network Stack
Ipv4 PXE Support	Disabled Enabled	Enables Ipv4 PXE Boot Support. If IPV4 is disabled, PXE boot option will not be created.
Ipv4 HTTP Support	Disabled Enabled	Enables Ipv4 HTTP Boot Support. If IPV4 is disabled, HTTP boot option will not be created.
Ipv6 PXE Support	Disabled Enabled	Enables Ipv6 PXE Boot Support. If IPV6 is disabled, PXE boot option will not be created.
Ipv6 HTTP Support	Disabled Enabled	Enables Ipv6 HTTP Boot Support. If IPV6 is disabled, HTTP boot option will not be created.
PXE boot wait time	0	Wait time to press <ESC> key to abort the PXE boot
Media detect count	1	Number of times the presence of media will be checked


CSM Configuration

This option allows you to enable or disable ROM execution settings.



Item	Option	Description
CSM Support	Disabled Enabled	Enables or disables CSM Support
Network	Do Not Launch UEFI Legacy	Controls the execution of UEFI and Legacy PXE OpROM
Storage	Do Not Launch UEFI Legacy	Controls the execution of UEFI and Legacy Storage OpROM
Video	Do Not Launch UEFI Legacy	Controls the execution of UEFI and Legacy Video OpROM
Other PCI device	Do Not Launch UEFI Legacy	Determines OpROM execution policy for devices other than Network, Storage, or Video

NVMe Configuration



Control Legacy PXE Boot


This option allows you to configure Legacy PXE boot settings.



Item	Option	Description
Control Legacy PXE Boot from	Disabled LAN1(i350) LAN2(i350)	Select On Board LAN# Boot

Platform Setup


Use [→] or [←] to select [Platform] setup screen. Under this screen, you may use [↑] [↓] to select an item you want to configure.



Item	Option	Description
PCH Configuration	None	Displays and provides option to change the PCH Settings
Server ME Configuration	None	Configure Server ME Technology Parameters
Runtime Error Logging	None	Press <Enter> to view or change the runtime error log configuration.

PCH Configuration


This option displays and provides options to change the PCH Settings.



Item	Option	Description
PCI Express Configuration	None	PCI Express Configuration settings
PCH sSATA Configuration	None	sSATA devices and settings
Restore AC Power Loss	Power On Power Off Last State	Select S0/S5 for ACPI state after a G3
Serial IRQ Mode	Quiet Continuous	Configure Serial IRQ Mode.

PCI Express Configuration



This option allows you to configure PCI express related options.



Item	Option	Description
PCIe Root Port Function Swapping	Disabled Enabled	Enable PCIe root port function swapping feature to dynamically assign function 0 to enabled root port.
Max Read Request Size	MRRS 128B MRRS 256B MRRS 512B MRRS 1024B MRRS 2048B MRRS 4096B	PCIe Max Read Request Size Selection.

PCH sSATA Configuration


This option allows you to configure SATA devices related options.



Item	Option	Description
SATA Controller	Disabled Enabled	Enables or disables SATA Controller
Configure SATA as	AHCI RAID	This will configure SATA as RAID or AHCI .
Support Aggressive Link Power Management	Disabled Enabled	Enables or disables SALP
Port 0/2/3/4/5	Disabled Enabled	Enable or Disable SATA Port
Hot Plug	Disabled Enabled	Designates this port as Hot Pluggable.
Configure as eSATA	Disabled Enabled	Configures port as External SATA (eSATA)
Spin Up Device	Disabled Enabled	If enabled for any of ports Staggered Spin Up will be performed and only the drives witch have this option enabled will spin up at boot. Otherwise all drives spin up at boot.
SATA Device Type	Hard Disk Drive Solid State Drive	Identify the SATA port is connected to Solid State Drive or Hard Disk Drive
SATA Topology	Unknown ISATA Direct Connect Flex M2	Identify the SATA Topology if it is Default or ISATA or Flex or Direct Connect or M2


Server ME Configuration

This option configures server ME technology parameters.



Runtime Error Logging


This option configures runtime error logging parameters.



Item	Option	Description
System Errors	Disabled Enabled	System Error Enable/Disable setup options.

Socket Setup

Use [→] or [←] to select [Socket] setup screen. Under this screen, you may use [↑] [↓] to select an item you want to configure.



Item	Option	Description
Processor Configuration	None	Displays and provides option to change the Processor Settings
Memory Configuration	None	Displays and provides option to change the Memory Settings
IIO Configuration	None	Displays and provides option to change the IIO Settings
Advanced Power Management Configuration	None	Displays and provides option to change the Power Management Settings
Numa	Disabled Enabled	Displays and provides option to change the Power Management Settings

Processor Configuration

In Processor Configuration, you can change the processor settings and view the current parameters.

Aptio Setup - AMI
Socket Configuration

Processor Configuration		Change Per-Socket Settings
▶ Per-Socket Configuration		
Processor BSP Revision	606A5 - ICX C0	
Processor Socket	Socket 0 Socket 1	
Processor ID	000606A5* 000606A5	
Processor Frequency	2.200GHz 2.200GHz	
Processor Max Ratio	16H 16H	
Processor Min Ratio	08H 08H	
Microcode Revision	8C000240 8C000240	
L1 Cache RAM(Per Core)	80KB 80KB	
L2 Cache RAM(Per Core)	1280KB 1280KB	
L3 Cache RAM(Per Package)	49152KB 49152KB	
Processor 0 Version	Genuine Intel(R) CPU \$0 000%@	↔: Select Screen
Processor 1 Version	Genuine Intel(R) CPU \$0 000%@	↑↓: Select Item
		Enter: Select
		+/-: Change Opt.
		F1: General Help
		F2: Previous Values
		F3: Optimized Defaults
		F4: Save & Exit
		ESC: Exit
Hyper-Threading [ALL]	[Enable]	
Machine Check	[Enable]	
Hardware Prefetcher	[Enable]	
Adjacent Cache Prefetch	[Enable]	
Extended APIC	[Disable]	
Enable Intel(R) TXT	[Disable]	
VMX	[Enable]	

Version 2.21.1278 Copyright (C) 2021 AMI

Aptio Setup - AMI
Socket Configuration


Processor Configuration		Enable/disable AES-NI support
▶ Per-Socket Configuration		
Processor BSP Revision	606A5 - ICX C0	
Processor Socket	Socket 0 Socket 1	
Processor ID	000606A5* 000606A5	
Processor Frequency	2.200GHz 2.200GHz	
Processor Max Ratio	16H 16H	
Processor Min Ratio	08H 08H	
Microcode Revision	8C000240 8C000240	
L1 Cache RAM(Per Core)	80KB 80KB	
L2 Cache RAM(Per Core)	1280KB 1280KB	
L3 Cache RAM(Per Package)	49152KB 49152KB	
Processor 0 Version	Genuine Intel(R) CPU \$0 000%@	↔: Select Screen
Processor 1 Version	Genuine Intel(R) CPU \$0 000%@	↑↓: Select Item
		Enter: Select
		+/-: Change Opt.
		F1: General Help
		F2: Previous Values
		F3: Optimized Defaults
		F4: Save & Exit
		ESC: Exit
Hyper-Threading [ALL]	[Enable]	
Machine Check	[Enable]	
Hardware Prefetcher	[Enable]	
Adjacent Cache Prefetch	[Enable]	
Extended APIC	[Disable]	
Enable Intel(R) TXT	[Disable]	
VMX	[Enable]	
Enable SMX	[Disable]	
AES-NI	[Enable]	

Version 2.21.1278 Copyright (C) 2021 AMI

Item	Option	Description
Hyper-Threading [ALL]	Disabled Enabled	Enables Hyper Threading (Software Method to Enable/ Disable Logical Processor threads.
Machine Check	Disabled Enabled	Enable or Disable the Machine Check
Hardware Prefetcher	Disabled Enabled	= MLC Streamer Prefetcher (MSR 1A4h Bit[0])
Adjacent Cache Prefetcher	Disabled Enabled	= MLC Spatial Prefetcher (MSR 1A4h Bit[1])
Extended APIC	Disabled Enabled	Enables or disables extended APIC support
Enable Intel® TXT	Disabled Enabled	Enables Intel(R) TXT
VMX	Disabled Enabled	Enables the Vanderpool Technology, which takes effect after reboot.
Enable SMX	Disabled Enabled	Enables Safer Mode Extensions
AES-NI	Disabled Enabled	Enables or disables AES-NI support


Per-Socket Configuration

Enter to configure the settings related to processor socket options.




Item	Option	Description
CPU Socket0 Configuration	None	None
CPU Socket1 Configuration	None	None

CPU Socket 0 Configuration



Item	Option	Description
Core Disable Bitmap (Hex)	0	0: Enable all cores. FFFFFFFF: Disable all cores least one core per CPU must be enabled. Disabling all cores is an invalid configuration.


CPU Socket 1 Configuration



Item	Option	Description
Core Disable Bitmap (Hex)	0	0: Enable all cores. FFFFFFFF: Disable all cores least one core per CPU must be enabled. Disabling all cores is an invalid configuration.

Memory Configuration

In Memory Configuration, you can change memory settings.




Item	Option	Description
Memory Frequency	Auto	Maximum Memory Frequency Selections in Mhz. Do not select Reserved
	1200	
	1333	
	1400	
	1600	
	1800	
	1866	
	2000	
	2133	
	2200	
	2400	
	2600	
	2666	
	2800	
	2933	
	3000	
3200		
	3400-OvrClk	
	3466-OvrClk	
	3600-OvrClk	

	3733-OvrClk 3800-OvrClk 4000-OvrClk 4200-OvrClk 4266-OvrClk 4400-OvrClk 4800-OvrClk	
Memory Topology	None	Displays memory topology with Dimm population information

I/O Configuration


In I/O Configuration, you can change socket settings and view the current parameters.



Item	Option	Description
Socket0 Configuration	None	None
Socket1 Configuration	None	None
IOAT Configuration	None	All IOAT configuration options
Intel® VT for Directed I/O (VT-d)	None	Press <Enter> to bring up the Intel® VT for Directed I/O (VT-d) Configuration menu.
Intel® VMD technology	None	Press <Enter> to bring up the Intel® VMD for Volume Management Device Configuration menu.
PCI-E ASPM Support (Global)	No Per-Port L1 Only	This option enables / disables the ASPM support for all downstream devices.
PCIe Extended Tag Enable	Auto No Yes	Auto/Enable - BIOS sets 8-bit Tag Field for PCIe Root Port/End Point. Disable - BIOS sets 5-bit Tag Field for PCIe Root Port/End Point
PCIe Max Read Request Size	Auto 128B 256B 512B 1024B 2048B 4096B	Set Max Read Request Size in End Points
Socket0 Configuration	None	None

Socket 0 Configuration


Enter to configure the settings related to PCI Express ports under Socket0.



Item	Option	Description
Socket 0 Port 1A	None	Settings related to PCI Express Port 1A
Socket 0 Port 2A	None	Settings related to PCI Express Port 2A
Socket 0 Port 2C	None	Settings related to PCI Express Port 2C
Socket 0 Port 4A	None	Settings related to PCI Express Port 4A
Socket 0 Port 4C	None	Settings related to PCI Express Port 4C
Socket 0 Port 5A	None	Settings related to PCI Express Port 5A


Socket 1 Configuration

Enter to configure the settings related to PCI Express ports under Socket1.




Item	Option	Description
Socket 1 Port 1A	None	Settings related to PCI Express Port 1A
Socket 1 Port 1C	None	Settings related to PCI Express Port 1C
Socket 1 Port 1D	None	Settings related to PCI Express Port 1D
Socket 1 Port 2A	None	Settings related to PCI Express Port 2A
Socket 1 Port 2C	None	Settings related to PCI Express Port 2C
Socket 1 Port 4A	None	Settings related to PCI Express Port 4A
Socket 1 Port 4C	None	Settings related to PCI Express Port 4C
Socket 1 Port 5A	None	Settings related to PCI Express Port 5A

IOAT Configuration





Item	Option	Description
Sck0 IOAT Config	None	None
Sck1 IOAT Config	None	None
Disable TPH	No Yes	TLP Processing Hint disable
Prioritize TPH	Disabled Enabled	Prioritize TPH
Relaxed Ordering	No Yes	Relaxed Ordering Enable/Disable

Intel® VT for Directed I/O (VT-d)




Item	Option	Description
Intel® VT for Directed I/O (VT-d)	No Yes	Press <Enter> to bring up the Intel® VT for Directed I/O (VT-d) Configuration menu.

Intel® VMD Technology




Advanced Power Management Configuration

In Advanced Power Management Configuration, you can modify power management settings.




Item	Option	Description
CPU P State Control	None	P State Control Configuration Sub Menu, include Turbo, XE and etc.
CPU C State Control	None	CPU C State setting

CPU P State Control



Item	Option	Description
SpeedStep(Pstates)	Disabled Enabled	Enables or disables EIST (P-States)
Boot performance mode	Max Performance Max Efficient Set by Intel Node Manager	Select the performance state that the BIOS will set before OS hand off.
CPU Flex Ratio Override	Disabled Enabled	Enable/Disable CPU Flex Ratio Programming
CPU Core Flex Ratio	23	Non-Turbo Mode Processor Core Ratio Multiplier


CPU C State Control



Item	Option	Description
CPU C1 auto demotion	Disabled Enabled	Autonomous Core C-State Control
CPU C6 report	Disabled Enabled	Enables or disables CPU C6(ACPI C3) report to OS
Enhanced Halt State (C1E)	Disabled Enabled	Core C1E auto promotion Control. Takes effect after reboot.

Server Mgmt Setup

Use [→] or [←] to select [Server Mgmt] setup screen. Under this screen, you may use [↑] [↓] to select an item you want to configure.




Item	Option	Description
BMC Support	Enabled Disabled	Enable or disables interfaces to communicate with BMC.
Wait For BMC	Enabled Disabled	Wait for BMC response for specified time-out. In PILOTII, BMC starts at the same time when BIOS starts during AC power ON. It takes around 30 seconds to initialize Host to BMC interfaces.
FRB-2 Timer	Enabled Disabled	Enables or disables FRB-2 timer (POST timer).
FRB-2 Timer timeout	3 minutes 4 minutes 5 minutes 6 minutes	Enter value Between 3 to 6 min for FRB-2 Timer Expiration value.
FRB-2 Timer Policy	Do Nothing Reset Power Down Power Cycle	Configure how the system should respond if the FRB-2 Timer expires. Not available if FRB-2 Timer is disabled.

OS Watchdog Timer	Enabled Disabled	If enabled, it starts a BIOS timer which can only be shut off by Management Software after the OS loads. It also helps verify that the OS is successfully loaded or follows the OS Boot Watchdog Timer policy.
OS Wtd Timer Timeout	5 minutes 10 minutes 15 minutes 20 minutes	Configure the length of the OS Boot Watchdog Timer. Not available if OS Boot Watchdog Timer is disabled.
OS Wtd Timer Policy	Do Nothing Reset Power Down Power Cycle	Configure how the system should respond if the OS Boot Watchdog Timer expires. Not available if OS Boot Watchdog Timer is disabled.
System Event Log	NA	Press <Enter> to change the SEL event log configuration.
BMC network configuration	NA	Configure BMC network parameters.
View System Event Log	NA	Press <Enter> to view the System Event Log Records.
BMC Warm Reset	NA	Press <Enter> to do Warm Reset BMC.

System Event Log


Use this option to change the SEL event log configuration.



Item	Option	Description
SEL Components	Disabled Enabled	Enables or disables all features of System Event Logging during boot.
Erase SEL	NO Yes, On next reset Yes, On every reset	Choose options for erasing SEL.
When SEL is Full	Do Nothing Erase Immediately Delete Oldest Record	Choose options for reactions to a full SEL.

BMC Network Configuration


This option allows you to configure BMC network parameters.



Item	Option	Description
Configuration Address source	Unspecified Static DynamicBmcDhcp	Select to configure LAN channel parameters statically or dynamically (by BIOS or BMC). The unspecified option will not modify any BMC network parameters during BIOS phase.


View System Event Log

This option allows you to view the System Event Log Records.



Security Setup


Use [←] / [→] to select [Security] setup screen. Under this screen, you may use [↑] [↓] to select an item you would like to configure.



Item	Description
Administrator Password	If ONLY the Administrator's password is set, it only limits access to Setup and is only asked for when entering Setup.
User Password	If ONLY the User's password is set, it serves as a power-on password and must be entered to boot or enter Setup. In Setup, the User will have Administrator rights.

Secure Boot


This option allows you to customize Secure Boot settings.



Item	Option	Description
Secure Boot	Disabled	Secure Boot is activated when Platform Key (PK) is enrolled, System mode is User/Deployed, and CSM function is disabled.
	Enabled	
Secure Boot Mode	Standard	Secure Boot mode selector: In Custom mode, Secure Boot Variables can be configured without authentication
	Custom	

Key Management


Allows you to provision advanced Secure Boot settings.



Item	Option	Description
Factory Key Provision	Disabled Enabled	Provision factory default keys on next re-boot only when System in Setup Mode.
Restore Factory keys	None	Force System to User Mode. Configure NVRAM to contain OEM-defined factory default Secure Boot keys.
Enroll Efi Image	None	Allows the image to run in Secure Boot mode. Enroll SHA256 hash of the binary into Authorized Signature Database (db)

Boot Setup

Use [←] / [→] to select [Boot] setup screen. Under this screen, you may use [↑] [↓] to select an item you would like to configure.



Item	Option	Description
Setup Prompt Timeout	5	The Number of seconds to wait for setup activation key. 65535 means indefinite waiting.
BootupNumLock State	On Off	Select the keyboard NumLock state.
Quiet Boot	Disabled Enabled	Enables or disables Quiet Boot option.
Boot mode select	LEGACY UEFI DUAL	Select boot mode for LEGACY or UEFI.

- Choose boot priority from boot option group.
- Choose specific boot device priority sequence from available Group device.


Save and Exit Setup

Use [←] / [→] to select [Save & Exit] setup screen. Under this screen, you may use [↑] [↓] to select an item you would like to configure.




■Discard Changes and Exit

Select this option to quit Setup without saving any modifications to the system configuration. The following window will appear after the "Discard Changes and Exit" option is selected. Select **"Yes"** to discard changes and Exit Setup.




■Save Changes and Reset

When Users have completed the system configuration changes, select this option to save the changes and reset from BIOS Setup in order for the new system configuration parameters to take effect. The following window will appear after selecting the **"Save Changes and Reset"** option is selected. Select **"Yes"** to Save Changes and reset.



■Restore Defaults

Restore default values for all setup options. Select "Yes" to load Optimized defaults.



Note: The items under Boot Override may not be the same images, it would depend on devices connected on the system.

NCA-6520 supports Intel® SGX Functional Tool, Intel® Boot Guard, and Secure Boot. For additional information on SGX Functional Tool, Boot Guard, and Secure Boot, please inquire Lanner Technical Support.

APPENDIX A: LED INDICATOR EXPLANATIONS

The status explanations of LED indicators on Front Panel are as follows:

LED indicators



▶ System Power

Solid Green	<i>The system is powered on</i>
Off	<i>The system is powered off</i>

▶ System Status

This LED indicator is programmable. You could program it to display the operating status of the behaviors described below:

Solid Green	<i>Defined by GPIO</i>
Solid Red	<i>Defined by GPIO</i>
Off	<i>Defined by GPIO</i>

▶ HDD Activity

If this LED blinks, it indicates data access activities; otherwise, it remains off.


Blinking Amber	<i>Indicates HDD activity including SATA / NVME</i>
Off	<i>No data access activity OR No power on</i>

Note:


1. When cable is plug-in and network is linked. Both LED will be light up.
2. Without the Cable plug-in, the LED should be off.
3. If LAN Driver control the LED, the behavior will follow the driver.

► **RJ-45 LAN LED Indicators**

10/100/1G
*Amber Green/
 Amber*



2.5G/10G
*Green Green/
 Amber*



► **10M/100M/1GB RJ-45 Define:**

Speed	Amber (Active)	Green/Amber (Link)
10M	Blinking Amber – Indicates data access	OFF
100M	Blinking Amber – Indicates data access	ON (Green)
1G	Blinking Amber – Indicates data access	ON (Amber)

► **2.5G / 10G RJ-45 define:**


Speed	Amber (Active)	Green/Amber (Link)
2.4G	Blinking Amber – Indicates data access	ON (Green)
10G	Blinking Amber – Indicates data access	ON (Green)

APPENDIX B: DUAL BIOS INTRODUCTION

Failure when booting up BIOS is not uncommon and can occur most often during a power failure, a mishandled BIOS update, a malware attack resulting in data corruption. When it happens, recovering procedures consume considerable time and effort. Lanner understands this pain and have empowered our products with the Dual BIOS feature.

How Dual BIOS Works

Dual BIOS features two physical BIOS ROMs soldered onto the motherboard, carrying two separate BIOS images. If the Primary BIOS (default) is not functioning correctly and fails to respond within seconds (~25 seconds to 2 minutes, depend upon appliance), the system will invoke a bootup from the Secondary BIOS, automatically restarting the system and launch the operating system.



2nd Gen Dual BIOS

To provide increased flexibility and usage protection, Lanner has released the 2nd Gen Dual BIOS function on Lanner appliances. With 2nd Gen Dual BIOS, both the primary BIOS and secondary BIOS can be updated and flashed using the BIOS Tool to run different versions of BIOS ROMS independently for maximum compatibility. This additionally allow users to switch BIOS ROMS for booting up, toggling between primary BIOS and secondary BIOS.

- **Flexible recovery timer control**

Users can designate the amount of time before recovery BIOS launch. The amount of time is no longer fixed to 7 minutes.

- **Flexible Dual BIOS ROMs control.**

Users can flash both the Primary BIOS and Secondary BIOS, thus run different versions of BIOS ROMS independently for maximum compatibility.

● **Flexible Dual BIOS ROMs switch**

The 2nd Gen Dual BIOS allow users to choose one of the BIOS ROMS (Primary BIOS/Secondary BIOS) for booting up. Use software command prompt to toggle between Primary BIOS and Secondary BIOS.

	Gen1 Dual BIOS	Gen2 Dual BIOS
Function	Primary / Recovery 2 ND BIOS for recovery purpose	Primary / Secondary (Peer to Peer) Both BIOS can let the system work
Detection Time	7 min	Seconds (By platform design)
2nd BIOS updated	Only using the SPI facility	By BIOS tool command or SPI facility
MAC/DMI	Only for BIOS1	For both BIOS
CPLD Interface	GPIO	LPC or eSPI (By Platform)

Figure 1. Gen 1 vs Gen 2 Dual BIOS comparison chart

Few things can shut down a computer as completely as a corrupted BIOS. With Dual BIOS feature, you will be guaranteed to enter a healthy OS to perform thorough troubleshooting before the situation is irreparable.

Get Ready for BIOS Update

Flashing a BIOS needs to be carefully completed, especially pertaining to a corrupted BIOS, which can lead to an unusable system if done incorrectly. To get ready for a BIOS update, acquire the following BIOS resources from Lanner technical support:

- Firmware and Flash Tool
- BIOS Engineering Spec

Before you start, make sure you select the correct firmware version, correct BIOS (Primary or Secondary) and go through the instructions for BIOS update in *BIOS Engineering Spec* thoroughly. If you cannot be certain if this version is correct for your system, please contact Lanner Technical Support.

 **Note:**

1. Dual BIOS feature cannot work with BIOS Boot Guard function
2. To update BIOS, it is mandatory to have both BIOS updated first. This is to avoid both BIOS having ME code variations, which could lead to unexpected risk and errors.
3. When the system enters BIOS menu or Option ROM, the system will not reboot automatically.



Warning

DO NOT power off or reset the system during BIOS updating process.

Disclaimer

Under no circumstances will Lanner accept responsibility or liability for damages of any kind whatsoever resulting or arising directly or indirectly from a BIOS update.

APPENDIX C: REDUNDANT POWER MODULE BEHAVIOR




Define the Alarm and Mute behavior

	Power Module Fail	Power Module Remove	Power Cord Remove
Buzzer	Alarm	Alarm	Alarm
Mute	Change back the Good PSU Module or Press the Mute Button	Put back the PSU Module or Press the Mute Button	Plug-in the Power cord or Press the Mute Button

Define the sequence of the Power Module

PSU Sequence The detection is from the left to the right side , from the bottom to the top side

Example :






APPENDIX D: FAN SEQUENCE

Define the sequence of the FAN


FAN Sequence The detection is from the left to the right side , from the bottom to the top side

Example:



APPENDIX E: SMART POWER & RESET BUTTON

Smart Power and Reset Button – Control by CPLD



APPENDIX F: ESD/SURGE ENHANCEMENT

Electrostatic Discharge (ESD): IEC-61000-4-2	Contact discharge	Air discharge	STD
Level 1	±2 kV	±2 kV	
Level 2	±4 kV	±4 kV	4K Contact
Level 3	±6 kV	±8 kV	8K Air
Level 4 (TBD)	±8 kV	±15 kV	New Requirement
			STD
Surge Immunity (LAN) IEC-61000-4-5	Test Level		
Level 0	25V		
Level 1	500V		
Level 2	1kV		V (Current)
Level 3 (TBD)	2kV		New Requirement
Level 4	4kV		
			STD
Electrical Fast Transient (EFT): IEC-61000-4-4			
Level 1	0.5kV		
Level 2	1kV		V (Current)
Level 3 (TBD)	2kV		New Requirement
Level 4	4kV		

APPENDIX G: TERMS AND CONDITIONS

Warranty Policy

1. All products are under warranty against defects in materials and workmanship for a period of one year from the date of purchase.
2. The buyer will bear the return freight charges for goods returned for repair within the warranty period; whereas the manufacturer will bear the after-service freight charges for goods returned to the user.
3. The buyer will pay for repair (for replaced components plus service time) and transportation charges (both ways) for items after the expiration of the warranty period.
4. If the RMA Service Request Form does not meet the stated requirement as listed on "RMA Service," RMA goods will be returned at customer's expense.
5. The following conditions are excluded from this warranty:
 - ▶ Improper or inadequate maintenance by the customer
 - ▶ Unauthorized modification, misuse, or reversed engineering of the product
 - ▶ Operation outside of the environmental specifications for the product.

RMA Service

Requesting an RMA#

1. To obtain an RMA number, simply fill out and fax the "RMA Request Form" to your supplier.
2. The customer is required to fill out the problem code as listed. If your problem is not among the codes listed, please write the symptom description in the remarks box.
3. Ship the defective unit(s) on freight prepaid terms. Use the original packing materials when possible.
4. Mark the RMA# clearly on the box.



Note: Customer is responsible for shipping damage(s) resulting from inadequate/loose packing of the defective unit(s). All RMA# are valid for 30 days only; RMA goods received after the effective RMA# period will be rejected.

RMA Service Request Form

When requesting RMA service, please fill out the following form. Without this form enclosed, your RMA cannot be processed.

RMA No:		Reasons to Return: <input type="checkbox"/> Repair(Please include failure details)	
		<input type="checkbox"/> Testing Purpose	
Company:		Contact Person:	
Phone No.		Purchased Date:	
Fax No.:		Applied Date:	
Return Shipping Address: _____			
Shipping by: <input type="checkbox"/> Air Freight <input type="checkbox"/> Sea <input type="checkbox"/> Express _____			
<input type="checkbox"/> Others: _____			
Item	Model Name	Serial Number	Configuration

Item	Problem Code	Failure Status

*Problem Code:

- | | | | |
|------------------------|------------------------------|--------------------|--------------------------|
| 01: D.O.A. | 07: BIOS Problem | 13: SCSI | 19: DIO |
| 02: Second Time R.M.A. | 08: Keyboard Controller Fail | 14: LPT Port | 20: Buzzer |
| 03: CMOS Data Lost | 09: Cache RMA Problem | 15: PS2 | 21: Shut Down |
| 04: FDC Fail | 10: Memory Socket Bad | 16: LAN | 22: Panel Fail |
| 05: HDC Fail | 11: Hang Up Software | 17: COM Port | 23: CRT Fail |
| 06: Bad Slot | 12: Out Look Damage | 18: Watchdog Timer | 24: Others (Pls specify) |

Request Party

Confirmed By Supplier

Authorized Signature / Date

Authorized Signature / Date