



Network Appliance Platform

Hardware Platforms for Network Computing

NCA-1040SE User Manual

Version: 2.2

Date of Release: 2025-07-30

About this Document

This manual describes the overview of the various functionalities of this product, and the information you need to get it ready for operation. It is intended for those who are:

- responsible for installing, administering and troubleshooting this system for Information Technology professionals.
- assumed to be qualified in the servicing of computer equipment, such as professional system integrators, or service personnel and technicians.

The latest version of this document can be found on Lanner's official website, available either through the product page or through the [Lanner Download Center](#) page with a login account and password.

Icon Description

The icons are used in the manual to serve as an indication of interest topics or important messages.

Icon	Usage
 Note or Information	This mark indicates that there is something you should pay special attention to while using the product.
 Warning or Important	This mark indicates that there is a caution or warning and it is something that could damage your property or product.

Online Resources

To obtain additional documentation resources and software updates for your system, please visit the [Lanner Download Center](#). As certain categories of documents are only available to users who are logged in, please be registered for a Lanner Account at <http://www.lannerinc.com/> to access published documents and downloadable resources.

Technical Support

In addition to contacting your distributor or sales representative, you could submit a request at our [Lanner Technical Support](#) and fill in a support ticket to our technical support department.

Documentation Feedback

Your feedback is valuable to us, as it will help us continue to provide you with more accurate and relevant documentation. To provide any feedback, comments or to report an error, please email contact@lannerinc.com. Thank you for your time.

Copyright and Trademarks

This document is copyrighted © 2025 by Lanner Electronics Inc. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, nor for any infringements upon the rights of third parties that may result from such use.

Contact Information

Taiwan Corporate Headquarters

Lanner Electronics Inc.

7F, No.173, Sec.2, Datong Rd.
Xizhi District, New Taipei City 22184,
Taiwan

立端科技股份有限公司

221 新北市汐止區
大同路二段 173 號 7 樓
T: +886-2-8692-6060
F: +886-2-8692-6101
E: contact@lannerinc.com

USA

Lanner Electronics Inc.

47790 Westinghouse Drive
Fremont, CA 94539
T: +1-855-852-6637
F: +1-510-979-0689
E: sales_us@lannerinc.com

Europe

Lanner Europe B.V.

Wilhelmina van Pruysenweg 104
2595 AN The Hague
The Netherlands
T: +31 70 701 3256
E: sales_eu@lannerinc.com

China

Beijing L&S Lancom Platform Tech. Co., Ltd.

Guodong LOFT 9 Layer No. 9 Huinan Road,
Huilongguan Town, Changping District, Beijing
102208 China
T: +86 010-82795600
F: +86 010-62963250
E: service@ls-china.com.cn

Canada

Lanner Electronics Canada Ltd

3160A Orlando Drive
Mississauga, ON
L4V 1R5 Canada
T: +1 877-813-2132
F: +1 905-362-2369
E: sales_ca@lannerinc.com

Acknowledgment

Intel® and Intel® Celeron® are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries. Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp. All other product names or trademarks are properties of their respective owners.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ Reorient or relocate the receiving antenna.
- ▶ Increase the separation between the equipment and receiver.
- ▶ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

- ▶ Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- ▶ This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Note

1. An unshielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.
2. Use only shielded cables to connect I/O devices to this equipment.
3. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Important

1. Operations in the 5.15-5.25GHz band are restricted to indoor usage only.
2. This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.



Important

IEC 61000-4-5: As stated above, surge testing is not required for the console if it is used under the following conditions,

- (1) Short cables only (<3m, temporary connection).
- (2) Indoor use only with no outdoor cable exposure.
- (3) Manufacturer specifies console is for service/maintenance only.

Safety Guidelines

Follow these guidelines to ensure general safety:

- ▶ Keep the chassis area clear and dust-free during and after installation.
- ▶ Do not wear loose clothing or jewelry that could get caught in the chassis. Fasten your tie or scarf and roll up your sleeves.
- ▶ Wear safety glasses if you are working under any conditions that might be hazardous to your eyes.
- ▶ Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- ▶ Disconnect all power by turning off the power and unplugging the power cord before installing or removing a chassis or working near power supplies
- ▶ Do not work alone if potentially hazardous conditions exist.
- ▶ Never assume that power is disconnected from a circuit; always check the circuit.

Consignes de sécurité

Suivez ces consignes pour assurer la sécurité générale :

- ▶ Laissez la zone du châssis propre et sans poussière pendant et après l'installation.
- ▶ Ne portez pas de vêtements amples ou de bijoux qui pourraient être pris dans le châssis. Attachez votre cravate ou écharpe et remontez vos manches.
- ▶ Portez des lunettes de sécurité pour protéger vos yeux.
- ▶ N'effectuez aucune action qui pourrait créer un danger pour d'autres ou rendre l'équipement dangereux.
- ▶ Coupez complètement l'alimentation en éteignant l'alimentation et en débranchant le cordon d'alimentation avant d'installer ou de retirer un châssis ou de travailler à proximité de sources d'alimentation.
- ▶ Ne travaillez pas seul si des conditions dangereuses sont présentes.
- ▶ Ne considérez jamais que l'alimentation est coupée d'un circuit, vérifiez toujours le circuit. Cet appareil génère, utilise et émet une énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions des fournisseurs de composants sans fil, il risque de provoquer des interférences dans les communications radio.

Lithium Battery Caution

- ▶ There is risk of explosion if the battery is replaced by an incorrect type.
- ▶ Dispose of used batteries according to the instructions.
- ▶ Installation should be conducted only by a trained electrician or only by an electrically trained person who knows all installation procedures and device specifications which are to be applied.
- ▶ Do not carry the handle of power supplies when moving to another place.
- ▶ Please conform to your local laws and regulations regarding safe disposal of lithium battery.
- ▶ Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery can result in an explosion.
- ▶ Leaving a battery in an extremely high temperature environment can result in an explosion or the leakage of flammable liquid or gas.
- ▶ A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.

Avertissement concernant la pile au lithium

- ▶ Risque d'explosion si la pile est remplacée par une autre d'un mauvais type.
- ▶ Jetez les piles usagées conformément aux instructions.
- ▶ L'installation doit être effectuée par un électricien formé ou une personne formée à l'électricité connaissant toutes les spécifications d'installation et d'appareil du produit.
- ▶ Ne transportez pas l'unité en la tenant par le câble d'alimentation lorsque vous déplacez l'appareil.

Operating Safety

- ▶ Electrical equipment generates heat. Ambient air temperature may not be adequate to cool equipment to acceptable operating temperatures without adequate circulation. Be sure that the room in which you choose to operate your system has adequate air circulation.
- ▶ Ensure that the chassis cover is secure. The chassis design allows cooling air to circulate effectively. An open chassis permits air leaks, which may interrupt and redirect the flow of cooling air from internal components.
- ▶ Electrostatic discharge (ESD) can damage equipment and impair electrical circuitry. ESD damage occurs when electronic components are improperly handled and can result in complete or intermittent failures. Be sure to follow ESD-prevention procedures when removing and replacing components to avoid these problems.

- ▶ Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. If no wrist strap is available, ground yourself by touching the metal part of the chassis.
- ▶ Periodically check the resistance value of the antistatic strap, which should be between 1 and 10 megohms (Mohms).

Sécurité de fonctionnement

- ▶ L'équipement électrique génère de la chaleur. La température ambiante peut ne pas être adéquate pour refroidir l'équipement à une température de fonctionnement acceptable sans circulation adaptée. Vérifiez que votre site propose une circulation d'air adéquate.
- ▶ Vérifiez que le couvercle du châssis est bien fixé. La conception du châssis permet à l'air de refroidissement de bien circuler. Un châssis ouvert laisse l'air s'échapper, ce qui peut interrompre et rediriger le flux d'air frais destiné aux composants internes.
- ▶ Les décharges électrostatiques (ESD) peuvent endommager l'équipement et gêner les circuits électriques. Des dégâts d'ESD surviennent lorsque des composants électroniques sont mal manipulés et peuvent causer des pannes totales ou intermittentes. Suivez les procédures de prévention d'ESD lors du retrait et du remplacement de composants.
- ▶ Portez un bracelet anti-ESD et veillez à ce qu'il soit bien au contact de la peau. Si aucun bracelet n'est disponible, reliez votre corps à la terre en touchant la partie métallique du châssis.
- ▶ Vérifiez régulièrement la valeur de résistance du bracelet antistatique, qui doit être comprise entre 1 et 10 mégohms (Mohms).

Mounting Installation Precautions

The following should be put into consideration for rack-mount or similar mounting installations:

- ▶ Do not install and/or operate this unit in any place that flammable objects are stored or used in.
- ▶ The installation of this product must be performed by trained specialists; otherwise, a non-specialist might create the risk of the system's falling to the ground or other damages.
- ▶ Lanner Electronics Inc. shall not be held liable for any losses resulting from insufficient strength for supporting the system or use of inappropriate installation components.
- ▶ Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.
- ▶ Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.
- ▶ Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
- ▶ Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
- ▶ Reliable Grounding - Reliable grounding of rack mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).

Installation & Operation


- ▶ This equipment must be grounded. The power cord for product should be connected to a socket-outlet with earthing connection.
Cet équipement doit être mis à la terre. La fiche d'alimentation doit être connectée à une prise de terre correctement câblée.
- ▶ Suitable for installation in Information Technology Rooms in accordance with Article 645 of the National Electrical Code and NFPA 75.
Peut être installé dans des salles de matériel de traitement de l'information conformément à l'article 645 du National Electrical Code et à la NFPA 75.
- ▶ The machine can only be used in a restricted access location and must be installed by a skilled person.
Les matériels sont destinés à être installés dans des EMPLACEMENTS À ACCÈS RESTREINT.
- ▶ Some USB devices may not be compatible with the system. If you encounter an error, please remove the USB device and restart the system.

Warning

- ▶ Class I Equipment. This equipment must be earthed. The power plug must be connected to a properly wired earth ground socket outlet. An improperly wired socket outlet could place hazardous voltages on accessible metal parts.
- ▶ Product shall be used with Class 1 laser device modules.

Avertissement

- ▶ Équipement de classe I. Ce matériel doit être relié à la terre. La fiche d'alimentation doit être raccordée à une prise de terre correctement câblée. Une prise de courant mal câblée pourrait induire des tensions dangereuses sur des parties métalliques accessibles.
- ▶ Le produit doit être utilisé avec des modules de dispositifs laser de classe 1.



Electrical Safety Instructions


Before turning on the device, ground the grounding cable of the equipment. Proper grounding (grounding) is very important to protect the equipment against the harmful effects of external noise and to reduce the risk of electrocution in the event of a lightning strike. To uninstall the equipment, disconnect the ground wire after turning off the power. A ground wire (green-and-yellow) is required and the part connecting the conductor must be greater than 4 mm² or 10 AWG.

Consignes de sécurité électrique

- ▶ Avant d'allumer l'appareil, reliez le câble de mise à la terre de l'équipement à la terre.
- ▶ Une bonne mise à la terre (connexion à la terre) est très importante pour protéger l'équipement contre les effets néfastes du bruit externe et réduire les risques d'électrocution en cas de foudre.
- ▶ Pour désinstaller l'équipement, débranchez le câble de mise à la terre après avoir éteint l'appareil.
- ▶ Un câble de mise à la terre est requis et la zone reliant les sections du conducteur doit faire plus de 4 mm² ou 10 AWG.

Grounding Procedure for DC Power Source

- ▶ Connect the grounding cable to the ground.
- ▶ The protection device for the DC power source must provide 30 A current.
- ▶ This protection device must be connected to the power source before DC power.



Procédure de mise à la terre pour source d'alimentation CC

- ▶ Branchez le câble de mise à la terre à la terre.
- ▶ L'appareil de protection pour la source d'alimentation CC doit fournir 30 A de courant.
- ▶ Cet appareil de protection doit être branché à la source d'alimentation avant l'alimentation CC.




Table of Contents

Chapter 1: Product Overview	10
Package Content.....	10
Ordering Information	10
System Specifications	11
Front Panel	12
Rear Panel.....	13
Chapter 2: Motherboard Information	14
Jumpers and Connectors.....	14
Chapter 3: Hardware Setup	22
Opening the Chassis	22
Installing the System Memory	23
Installing M.2 Storage Card (Optional).....	24
Installing LTE/5G Module Card (Optional, SKU A/B Only).....	25
Installing Wi-Fi Module Card (Optional, SKU A/B Only).....	29
Installing SIM card (Optional, SKU A/B Only)	32
Single Device Rackmount (Optional).....	33
Dual Device Rackmount (Optional)	35
Wallmount the System (Optional)	37
Chapter 4: BIOS Setup.....	39
Main Page.....	40
Advanced	41
Chipset.....	55
Security.....	58

Boot Menu.....61

Save and Exit Menu62

Appendix A: LED Indicator Explanations..... 64

Appendix B: Terms and Conditions..... 65

Warranty Policy65

CHAPTER 1: PRODUCT OVERVIEW

NCA-1040SE is a compact desktop appliance empowered by Intel® Atom® x6413E / Intel® Celeron® N6210/J6412 (codenamed Elkhart lake) processor. The NCA-1040SE's form factor, relatively low power consumption, robust processing capability, up to 32GB DDR4 3200MHz SODIMM and its various I/O ports together make it ideal for edge deployments, branch offices and retail settings.

Package Content

Your package contains the following items:

- ▶ 1x NCA-1040SE Network Security Platform
- ▶ 1x Power Adaptor
- ▶ 1x Power Cable
- ▶ 1x Console Cable
- ▶ 4x Rubber Foot

Ordering Information

SKU No.	Main Features
NCA-1040SEA	4-core 1.5GHz, Intel® Atom® X6413E (Elkhart Lake), 4x 2.5GbE RJ45 (with 1st Port support PoE+), 1x DDR4 SO-DIMM, 1x M.2 for Wi-Fi/LTE/5G, 1x Mini-PCIe slot for Wi-Fi, TPM 2.0 onboard, 40W Adapter
NCA-1040SEB	4-core 2.0GHz, Intel® Celeron® J6412 (Elkhart Lake), 4x 2.5GbE RJ45 (with 1st Port support PoE+), 1x DDR4 SO-DIMM, 1x M.2 for Wi-Fi/LTE/5G, 1x Mini-PCIe slot for Wi-Fi, TPM 2.0 onboard, 40W Adapter
NCA-1040SEC	2-core 1.2GHz, Intel® Celeron® N6210 (Elkhart Lake), 4x 2.5GbE RJ45, 1x DDR4 SO-DIMM, 40W Adapter

System Specifications

Form Factor		Fanless Desktop
Platform	Processor Options	SKU A: Intel® Atom® X6413E (Elkhart Lake) SKU B: Intel® Celeron® J6412 (Elkhart Lake) SKU C: Intel® Celeron® N6210 (Elkhart Lake)
	Frequency	1.5GHz/2.0GHz/1.2GHz
	CPU Cores	4 / 4 / 2
	Chipset	SoC
BIOS		AMI SPI Flash BIOS
System Memory	Technology	DDR4 3200MT/s SO-DIMM
	Max. Capacity	Up to 32 GB
	Socket	1x 260pin SO-DIMM
Networking	Controller	Intel® i226V
	Interface	4x 2.5GbE RJ45 Ports (1x PoE+ Port)
PoE+ Support	# of PoE+ (PSE) Ports	SKU A/B: 1x PoE+ Port (Optional) SKU C: N/A
	Standard	IEEE 802.3at
	PoE+ Power Input	4-pin power connector with 65W PoE+ adapter
I/O Interface	Reset Button	1x Reset Button
	LED Indicators	Power/Status/Storage/M.2/Mini PCIe, refer to Appendix A
	Power Button	1x Power Button with LED
	Console Port	1x RJ45 (Default Baud rate : 115200) Console Port
	USB Port	1x USB 3.0 Port
	Display Port	1x Display Port (without Audio Function)
	Power Input	1x DC Jack with Lock
Storage		Antenna Hole 4x Antenna Holes for Wi-Fi/LTE/5G (SKU A/B Only)
Expansion	Onboard Slots	1x M.2 (SATA) 2280 B-Key
	Mini-PCIe/M.2	SKU A/B : 1x Mini-PCIe (PCIe/USB2.0) for Wi-Fi ; 1x M.2 3042/3052 B-Key for 5G/LTE SKU C : N/A
	SIM Card Slot	SKU A/B : 2x Nano SIM Card Slots SKU C : N/A
Miscellaneous	Watchdog	YES
	Internal RTC with Li Battery	YES
	TPM	SKU A/B: YES, TPM 2.0 on board SKU C: N/A
Cooling	System	Fanless (Default), 1x 5-pin Fan Connector (By Project)
Environmental	Temperature	0~40°C Operating, -20~70°C Non-Operating
	Humidity (RH)	5~90% Operating, 5~ 95% Non-Operating
Mechanical	Dimension (WxDxH)	183 x 168 x 32mm
	Weight	0.9 kg
	Mounting	Rackmount; Wall Mount (Optional Kit)
Power	Type/Watts	1x 40W Power Adapter
	Input	AC 100~240V @50~60 Hz
OS Support		Linux, Yocto
Approvals and Compliance		RoHS, CE/FCC Class B (Class A with PoE), UL, VCCI, UKCA

Front Panel



No.	Description	
F1	Antennas	2x SMA Antenna Holes (SKU A/B Only: Support Wi-Fi/LTE/5G Module)
F2	Reset Button	1x Reset Button
F3	LED Indicators	Power/Status/Storage/M.2/Mini-PCle, refer to Appendix A
F4	Console Port	1x RJ45 Console Port
F5	USB Port	1x USB 3.0 Port

Rear Panel



No.	Description	
R1	Antennas	2x SMA Antenna Holes (SKU A/B Only: Support Wi-Fi/LTE/5G Module)
R2	Power Button	1x Power Button with LED
R3	Power Inlet	1x DC Jack with Lock
R4	PoE+ (PSE) Input	1x 4-pin 54V Input Port with Lock (ATX4P) for PoE+ (Optional, SKU A/B Only)
R5	PoE+ Port	1x PoE+ Port
R6	LAN Ports	3x 2.5GbE RJ45 Ethernet Ports with LED
R7	Display Port	1x Display Port (without Audio Function)




Note

1. To enable PoE+ support on the first LAN port, it is necessary to integrate the PoE+ power adapter kit (PSF9758-001).
2. Certification is restricted to FCC Class A when using PoE. (Class B certification is available when PoE is not in use.)

CHAPTER 2: MOTHERBOARD INFORMATION

Jumpers and Connectors

The following displays the connectors and jumpers on the motherboard layout.




Jumper Setting and Connector Pin-out

The following references the pin assignments and internal connectors of NCA-1040SE.


JCOMS1: RTC Reset

Pin	Description
1-2	Clear RTC_TEST
2-3	Clear RTC_RST




J8: Reset Option

Pin	Description
1-2	Hardware Reset
2-3 (Default)	Software Reset




PW2: Power Supply Connector of PSE

Pin	Description
1	GND
2	GND
3	+P54V
4	+P54V




JPW1: SATA Power Connector 1x4 Pins 2.54mm

Pin	Description
1	+P12V_S
2	GND
3	GND
4	+P5V_S




LAN1: 1x4 RJ45 w/o transformer

Pin	Description
1	MD0+
2	MD0-
3	MD1+
4	MD2+
5	MD2-
6	MD1-
7	MD3+
8	MD3-




COM1: RJ45 Console


Pin	Description
1	Request to Send (RTS)
2	NC
3	Transmitted Data (TxD)
4	Signal Ground
5	Signal Ground
6	Received Data (RxD)
7	NC
8	Clear to Send (CTS)

**USB1: USB 3.0 single CONN**

Pin	Description
1	+P5V_USB1
2	USB20_N1
3	USB20_P1
4	GND
5	USB30_RXN0
6	USB30_RXP0
7	GND
8	USB30_TXN0
9	USB30_TXP0


**DP1: Display Port 20P 0.6mm**

Pin	Description	Pin	Description
1	DP1_C_DATA0	11	GND
2	GND	12	DP1_C_DATAN3
3	DP1_C_DATAN0	13	DDI1_AUX_EN_P13
4	DP1_C_DATA0	14	CONFIG2
5	GND	15	DDI1_DDC_CLK_AUX_DP
6	DP1_C_DATAN1	16	GND
7	DP1_C_DATA0	17	DDI1_DDC_DAT_AUX_DN
8	GND	18	DP1_HPD
9	DP1_C_DATAN2	19	GND
10	DP1_C_DATA0	20	+P3V3_DP



SIM1/2: Nano SIM push-push


Pin	Description
1	UIMx_PWR
2	UIMx_RST#
3	UIMx_CLK
4	UIMx_DETECT
5	GND
6	NC
7	UIMx_DAT

**SATA1:180° SATA Connector**

Pin	Description
1	GND
2	TX+
3	TX-
4	GND
5	RX-
6	RX+
7	GND

**PCIE1: Mini-PCle Socket**


Pin	Description	Pin	Description
1	NC, PMC_WAKE#	27	GND
2	+P3V3_S	28	+P1V5_S
3	NC	29	GND
4	GND	30	NC, SMB_CLK
5	NC	31	PCIE_TXN
6	+P1V5_S	32	NC, SMB_DATA
7	PCIE_CLKREQ5#	33	PCIE_TXP
8	NC	34	GND
9	GND	35	GND
10	NC	36	USB20_N0
11	REFCLK-	37	GND
12	NC	38	USB20_P0
13	REFCLK+	39	+P3V3_S
14	NC	40	GND
15	GND	41	+P3V3_S
16	NC	42	NC
17	NC	43	GND



18	GND	44	LED_WLAN_N
19	NC	45	NC
20	PH, +P3V3_S	46	NC
21	GND	47	NC
22	MPCIE_RST#	48	+P1V5_S
23	PCIE_RXN	49	NC
24	+P3V3_S	50	GND
25	PCIE_RXP	51	NC
26	GND	52	+P3V3_S

M2_1: M.2 B-Key for Storage


Pin	Description	Pin	Description
1	NC	2	+P3V3_S
3	GND	4	+P3V3_S
5	GND	6	NC
7	NC	8	NC
9	NC	10	NC
11	GND	12	B-KEY
13	B-KEY	14	B-KEY
15	B-KEY	16	B-KEY
17	B-KEY	18	B-KEY
19	B-KEY	20	NC
21	NC	22	NC
23	NC	24	NC
25	NC	26	NC
27	GND	28	NC
29	NC	30	NC
31	NC	32	NC
33	GND	34	NC
35	NC	36	NC
37	NC	38	NC
39	GND	40	NC
41	SATA_C_RXP0	42	NC
43	SATA_C_RXN0	44	NC
45	GND	46	NC
47	SATA_C_TXN0	48	NC
49	SATA_C_TXP0	50	NC
51	GND	52	NC



53	NC	54	NC
55	NC	56	NC
57	GND	58	NC
59	NC	60	NC
61	NC	62	NC
63	NC	64	NC
65	NC	66	NC
67	NC	68	NC
69	GND	70	+P3V3_S
71	GND	72	+P3V3_S
73	GND	74	+P3V3_S
75	NC		

M2_B_KEY1: M.2 B-Key for 4G/5G


Pin	Description	Pin	Description
1	NC	2	+P3V3_A
3	GND	4	+P3V3_A
5	GND	6	PH, +P1V8_A
7	USB2_DP0	8	PH, +P3V3_A
9	USB2_DN0	10	LED_M2_WWAN_N
11	GND	12	B-KEY
13	B-KEY	14	B-KEY
15	B-KEY	16	B-KEY
17	B-KEY	18	B-KEY
19	B-KEY	20	PH, +P1V8_A
21	GND	22	PH, +P3V3_A
23	NC, WAKE_UP#	24	NC
25	DPR	26	PH, +P3V3_A
27	GND	28	NC
29	M2_USB30_TXN2	30	UIM1_RST#
31	M2_USB30_TXP2	32	UIM1_CLK
33	GND	34	UIM1_DAT
35	M2_USB30_RXN2	36	UIM1_PWR
37	M2_USB30_RXP2	38	NC
39	GND	40	UIM2_DETECT
41	M2_PCIE_RXN1	42	UIM2_DAT
43	M2_PCIE_RXP1	44	UIM2_CLK
45	GND	46	UIM2_RST#




47	M2_PCIE_TXN1	48	UIM2_PWR
49	M2_PCIE_TXP1	50	NC, PCIE_B_RST#
51	GND	52	NC, M2_PCIE_CLKREQ1#
53	M2_PCIE_CLKN	54	NC, B_WAKE#
55	M2_PCIE_CLKP	56	NC
57	GND	58	NC
59	NC	60	NC
61	NC	62	NC
63	NC	64	NC
65	NC	66	UIM1_DETECT
67	NC, M2_RESET#	68	NC
69	GND	70	+P3V3_A
71	GND	72	+P3V3_A
73	GND	74	+P3V3_A
75	NC		

JFAN1: DIP 2.54mm 5-Pin Fan Connector

Pin	Description
1	GND
2	TX+
3	TX-
4	GND
5	RX-
6	RX+
7	GND


**JUSBDM1: DIP 2.54mm 2x5 Box Header R/A Type**

Pin	Description
1	+P5V_USB2
2	NC
3	USB20_L_N
4	NC
5	USB20_L_P
6	NC
7	GND
8	NC
9	NC,USB_R_WP
10	NC




JDI01: DIP 2.0mm 2x3 Pin Header


Pin	Description
1	DIO_GPI_1
2	DIO_GPO_1
3	DIO_GPI_2
4	DIO_GPO_2
5	GND
6	GND

**JSPI1: SMD 2.0mm 2x5 Pin Header**

Pin	Description	Pin	Description
1	SPI0_IO3_HOLD#	2	NC
3	SPI0_CS0_R#	4	V_3P3_SPI
5	SPI0_IO1_MISO_R	6	NC
7	NC	8	SPI0_CLK_R
9	GND	10	SPI0_IO0_MOSI_R

**J2: DIP 2.43mm 1x3 Pin Header for VCCIN debug**

Pin	Description
1	SMB_DATA_VR
2	SMB_CLK_VR
3	GND



CHAPTER 3: HARDWARE SETUP

To reduce the risk of personal injury, electric shock, or damage to the system, please remove all power connections to shut down the device completely and wear ESD protection gloves when handling the installation steps.

Opening the Chassis


1. Power off the system and remove all power connections.
2. Turn the system upside down, with its bottom side facing up, and locate the four footing screws.
3. Remove the four (4) screws.
4. Turn the system right side up and gently lift the top chassis up.



Installing the System Memory

The motherboard supports a DIMM DDR4 3200MHz non-ECC up to 32GB, which is located on the bottom side of the motherboard. Please follow the steps below to install the DIMM memory module properly.


1. Power off the system.
2. Turn the system upside down, with its bottom side facing up.
3. Locate the DIMM socket cover.



4. Unscrew the one (1) screw securing the cover. And gently lift up the DIMM socket cover.



5. Align the notch of the DIMM card with the socket key in the pin slot.
6. Insert the DIMM card at 30 degrees into the socket until it is fully seated.



7. Push down on the module card until the slot latches catches and clicks into place.



Installing M.2 Storage Card (Optional)

The system supports one M.2 slot for additional data storage (SSD is recommended due to heat and vibration concerns). Please follow the steps for installation.

1. Power off the system and open the chassis cover.
2. Locate the M.2 slot on the motherboard.




3. Align the notch of the M.2 memory card with the socket key in the pin slot.



4. Insert the M.2 memory card pins at 30 degrees into the socket until it is fully seated.
5. Push down on the module card and secure it with a screw.



6. Next, thermal pad placement. Remove the protective film on the rectangular thermal pad (included in the accessory pack) and gently place on the underside of the chassis cover (which once covered, will be placed over the Memory module.)




Installing LTE/5G Module Card (Optional, SKU A/B Only)


The motherboard provides one M.2 slot for one LTE/5G module card. Therefore, only one LTE module or one 5G module can be installed. LTE module requires two (2) antennas, and 5G module requires four (4) antennas. Please follow the procedures for 5G module card expansion installation.

The LTE/5G Module Kit will include:


- ▶ 1x LTE/5G Module Card
- ▶ 2x or 4x SMA Cable Sets
- ▶ 2x or 4x Antennas
- ▶ 1x Standoff Set w/ Screw
- ▶ 2x Thermal pads




1. Power off the system and open the chassis cover.
2. Locate the M.2 slot on the motherboard. Position the Standoff set and secure with a screw.
3. Remove the protective film on the square thermal pad and gently place on the motherboard.




4. Align the notch of the LTE/5G module card with the socket key in the pin slot.
5. Insert the LTE/5G module card pins at 30 degrees into the socket until it is fully seated.



6. Push down on the module card and secure it with a screw.



7. Remove the protective film on the second square thermal pad and gently place on the underside of the chassis cover (which once covered, will be placed over the 5G/LTE module.)



Installing 5G Antennas

Front Panel




Rear Panel



1. Locate the four (4) antenna hole placements (A1, A2, A3, A4). Locate the four (4) IPEX connectors on the 5G module card.




2. Connect RF cables to the 5G module card.




3. From inside the chassis, insert the SMA Bulkhead through the antenna hole on the panel.

On the outside of the system, attach the Washer and Nut, and tighten the Nut using an SMA Torque Wrench.



4. Screw on the four (4) antennas to the system.



Installing Wi-Fi Module Card (Optional, SKU A/B Only)


The system supports one mini-PCIe slot for a Wi-Fi or BT module card. Please follow the steps to install the Wi-Fi module card. Wi-Fi module requires two antennas.

1. Power off the system and open the chassis cover.
2. Locate the mPCIe slot on the motherboard.



3. Align the notch of the Wi-Fi module card with the socket key in the pin slot.


4. Insert the Wi-Fi module card pins at 30 degrees into the socket until it is fully seated.



5. Push down on the module card and secure it with a screw.



6. Remove the protective film on the second square thermal pad and gently place on the underside of the chassis cover (which once covered, will be placed over the Wi-Fi module.)




Installing Wi-Fi Antennas

Rear Panel



1. Locate the two (2) antenna RF cables. Locate the two (2) IPEX connectors on the Wi-Fi module card
2. Connect the RF cables to the Wi-Fi module card.





3. Screw on the two (2) antennas to the system.



Installing SIM card (Optional, SKU A/B Only)

The SIM slot on the bottom panel supports the LTE/5G module card. Please follow the steps below for SIM card placement.

1. Power off the system.
2. Turn the system upside down, with its bottom side facing up.
3. Locate the SIM slot cover.



4. Unscrew the one (1) screw securing the cover. And gently remove the SIM slot cover.
5. Insert and push the nano-SIM card all the way in until it clicks into place.




6. To remove the SIM card, use your fingertips to push it once, to have the card automatically eject.
7. Place the slot door back and tighten the one (1) screw.

Single Device Rackmount (Optional)


With a single device rackmount kit, one NCA-1040SE can be installed into a rack. Please contact Lanner's sales representative for purchasing the rackmount kit.

The rackmount kit contains the following:


- ▶ 1x Rackmount Bracket
- ▶ 5x Zip Ties
- ▶ 1x Screw pack (bracket screws and rack mounting screws)




1. The system should be placed in the middle of the rackmount bracket, with the adapter holder section holding the power adapter and PoE adapter. Place the system into the rackmount bracket, and secure with three (3) screws on the back side.



2. Next, place the power adapter on the adapter holder section, and secure with two (2) zip ties.



3. Then, we place the PoE adapter in the adapter holder section, and secure with two (2) zip ties. Also secure the cables with a zip tie.



4. Attach the power adapter and PoE adapter connector to the system's rear panel.



Installing the System to the Rack

1. Hold the system with its front facing, and lift carefully to insert the system into the rack. Attach the brackets to the rail rack using rack-mounting screws. It is also recommended to install a shelf in the rack to support the system.




Dual Device Rackmount (Optional)


With a dual device rackmount kit, two NCA-1040SE can be installed into a rack. Please contact Lanner's sales representative for purchasing the rackmount kit.

The Rackmount kit contains the following:


- ▶ 1x Rackmount Bracket
- ▶ 1x Zip Ties Pack
- ▶ 1x Screw Pack (bracket screws and rack mounting screws)



1. The two system should be placed in the center of the rackmount bracket, with the adapter holder section holding the power adapter and PoE adapter. Place the system into the rackmount bracket, and secure with four (4) screws each on the back side.



2. Next, place the power adapter and PoE adapter (optional), for each system, on the adapter holder section, and secure with zip ties. Also secure the cables with a zip tie.



3. Attach the power adapter and PoE adapter connector to the system's rear panel.



Installing the System to the Rack

1. Hold the system with its front facing, and lift carefully to insert the system into the rack. Attach the brackets to the rail rack using rack-mounting screws. It is also recommended to install a shelf in the rack to support the system.



Wallmount the System (Optional)


With the wall mount kit, this system can be fixed on a flat wall surface. Please contact Lanner sales representative for purchasing this kit.

The Wall-mount Kit contains for the following items:

- ▶ 2x Wall Brackets
- ▶ 1x Screws Pack




1. Turn the system over, and fix the wall brackets onto the bottom side of the system, secure with the four (4) provided screws.





2. On the wall, measure the exact place where you want to mount the system, and drill four holes that match the four mounting holes on the brackets.

Note: the demonstrated screw type can fit in general drywall or shelves. Please identify the wall type and select a suitable fixing approach to fix this system to the wall and consult qualified trained person if you are unsure.




3. Insert the wall plugs into the holes.
4. Then, insert the long screws into the wall screws.



5. Align the four screw holes on the system's wall brackets with the four long screws you just installed on the wall.



6. Engage the four screws in the bracket holes and push the system downwards to lock the screws into position.



CHAPTER 4: BIOS SETUP

BIOS (Basic Input / Output System) is the program that controls the computer boot process.

Entering Setup

BIOS is a firmware embedded on an exclusive chip on the system's motherboard. Lanner's BIOS firmware offering including market-proven technologies such as Secure Boot and Intel Boot Guard technology deliver solid commitments for the shield protection against malware, uncertified sequences and other named cyber threats.

To enter the BIOS setup utility, simply follow the steps below:

1. Boot up the system.
2. Pressing the **<Tab>** or **** key immediately allows you to enter the Setup utility, and then you will be directed to the BIOS main screen. The instructions for BIOS navigations are as below:

Control Keys	Description
→←	select a setup screen
↑↓	select an item/option on a setup screen
<Enter>	select an item/option or enter a sub-menu
+/-	adjust values for the selected setup item/option
F1	display General Help screen
F2	retrieve previous values, such as the last configured parameters during the last time you entered BIOS
F3	load optimized default values
F4	save configurations and exit BIOS
<Esc>	exit the current screen



Note: The images in the following section are for reference only.

Main Page


Setup main page contains BIOS information and project version information.



Feature	Description
BIOS Information	BIOS Vendor: American Megatrends Core Version: AMI Kernel version, CRB code base, X64 Compliance: UEFI version, PI version Project Version: BIOS release version Build Date and Time: MM/DD/YYYY Access Level: Administrator / User
FSP Information	FSP version: Intel FSP binary version. RC version: Intel reference code version.
System Date	To set the Date, use <Tab> to switch between Date elements. Default Range of Year: 2005-2099 Default Range of Month: 1-12 Days: dependent on Month.
System Time	To set the Date, use <Tab> to switch between Date elements.

Advanced

Select the **Advanced** menu item from the BIOS setup screen to enter the "Advanced" setup screen. Users can select any of the items in the left frame of the screen.




CPU Configuration





Feature	Options	Description
Hardware Prefetcher	Enabled Disabled	To turn ON/OFF the MLC streamer prefetcher
Adjacent Cache Line Prefetch	Enabled Disabled	To turn ON/OFF prefetching of adjacent cache lines.
Intel (VMX) Virtualization Technology	Enabled Disabled	Intel (VMX) Virtualization Technology
AES	Enabled Disabled	Enable/Disable AES (Advanced Encryption Standard)
MonitorMWait	Enabled Disabled	Enable/Disable MonitorMWait
AC Split Lock	Enabled Disabled	Enable/Disable AC Split Lock

Power & Performance



Feature	Options	Description
Boot Performance Mode	Max Battery	Select the performance state that the BIOS will set starting from reset vector.
	Max	
	Non-Turbo Performance	
Intel® SpeedStep™	Turbo Performance	Allows more than two frequency ranges to be supported.
	Enabled	
RC6 (Render Standby)	Disabled	Check to enable render standby support.
	Enabled	
Disable Turbo GT Frequency	Disabled	Enabled: Disables Turbo GT frequency. Disabled: GT frequency is not limited.
	Enabled	

PCH-FW Configuration



Feature	Options	Description
Me FW Image Re-Flash	Enabled Disabled	Enable/Disable ME FW Update function.

Trusted Computing





Feature	Options	Description
Security Device Support	Enabled Disabled	Enables or disables BIOS support for security device. By disabling this function, OS will not show Security Device. TCG EFI protocol and INT1A interface will not be available.
SHA-1 PCR Bank	Enabled Disabled	Enables or disables SHA-1 PCR Bank.
SHA256 PCR Bank	Enabled Disabled	Enables or disables SHA256 PCR Bank
Pending Operation	None TPM Clear	Schedules an Operation for the Security Device. NOTE: Your computer will reboot during restart in order to change State of Security Device.
Platform Hierarchy	Enabled Disabled	Enables or disables Platform Hierarchy.
Storage Hierarchy	Enabled Disabled	Enables or disables Storage Hierarchy
Endorsement Hierarchy	Enabled Disabled	Enables or disables Endorsement Hierarchy.

Control PXE Boot


Feature	Options	Description
Control Legacy PXE Boot From	Disabled LAN1 LAN2 LAN3 LAN4	Control PXE Boot from which LAN.

Super IO Configuration



Feature	Options	Description
Serial Port	Enabled Disabled	Enables or Disables Serial Port 1
Device Settings	NA	IO=3F8h; IRQ=4

H/W Monitor



Serial Port Console Redirection

Aptio Setup - AMI

Advanced

COM0

Console Redirection [Enabled]

> Console Redirection Settings

Console Redirection

Enable or Disable.

><: Select Screen

^v: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults


F4: Save & Exit

ESC: Exit

Version 2.21.1278 Copyright (C) 2021 AMI

Feature	Options	Description
Console Redirection	Enabled Disabled	Enables or Disables Console Redirection


Console Redirection Settings



Feature	Options	Description
Terminal Type	VT100	VT100: ASCII char set
	VT100+	VT100+: Extends VT100 to support color, function keys, etc.
	VT-UTF8	VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes
	ANSI	
Bits per second	9600	Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
	19200	
	38400	
	57600	
	115200	
Data Bits	7	Data Bits
	8	
Parity	None	A parity bit can be sent with the data bits to detect some transmission errors.
	Even	
	Odd	
	Mark	
Stop Bits	1	Indicates the end of a serial data packet.
	2	


Flow Control	None Hardware RTS/CTS	Flow Control can prevent data loss from buffer overflow.
VT-UTF8 Combo Key Support	Disabled Enabled	Enables VT-UTF8 Combination Key Support for ANSI/VT100 terminals
Recorder Mode	Disabled Enabled	With this mode enabled, only text will be sent. This is to capture Terminal data
Resolution 100x31	Disabled Enabled	Enables or disables extended terminal resolution
Putty KeyPad	VT100 LINUX XTERM86 SCO ESCN VT400	Selects FunctionKey and Keypad on Putty

PCI Subsystem Settings




Feature	Options	Description
SR-IOV Support	Disabled Enabled	If the system has SR-IOV capable PCIe Devices, this option enables or disables Single Root IO Virtualization Support.

USB Configuration




Feature	Options	Description
Legacy USB Support	Enabled Disabled Auto	Enables Legacy USB support. Auto option disables legacy support if no USB devices are connected; Disabled option will keep USB devices available only for EFI applications
XHCI Hand-off	Enabled Disabled	This is a workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
USB Mass Storage Driver Support	Enabled Disabled	Enables or disables USB Mass Storage Driver Support
USB transfer time-out	1 sec 5 sec 10 sec 20 sec	The time-out value for Control, Bulk, and Interrupt transfers
Device reset time-out	1 sec 5 sec 10 sec 20 sec	USB mass storage device Start Unit command time-out
Device power-up delay	Auto Manual	Maximum time the device will take before it properly reports itself to the Host Controller. Auto uses default value: for a Root port, it is 100ms, for a Hub port the delay is taken from Hub descriptor.

Network Stack Configuration




Feature	Options	Description
Network Stack	Disabled Enabled	Enables or disables UEFI Network Stack
IPv4 PXE Support	Disabled Enabled	Enables IPv4 PXE Boot Support. If IPv4 is disabled, PXE boot option will not be created.
IPv4 HTTP Support	Disabled Enabled	Enables IPv4 HTTP Boot Support. If IPv4 is disabled, HTTP boot option will not be created.
IPv6 PXE Support	Disabled Enabled	Enables IPv6 PXE Boot Support. If IPv6 is disabled, PXE boot option will not be created.
IPv6 HTTP Support	Disabled Enabled	Enables IPv6 HTTP Boot Support. If IPv6 is disabled, HTTP boot option will not be created.
PXE boot wait time	0	Wait time to press <ESC> key to abort the PXE boot
Media detect count	1	Number of times the presence of media will be checked.

Chipset




System Agent (SA) Configuration



Feature	Options	Description
VT-d	Disable	VT-d capability.
	Enable	Option to Enable/Disable VT-d.
X2APIC Opt Out	Disable	Enable/Disable X2APIC_OPT_OUT
	Enable	

PCH-IO Configuration



Feature	Options	Description
SATA Controller(s)	Disabled Enabled	Enables/Disables SATA controller
SATA Mode Selection	AHCI	SATA mode support.


Security

Select the Security menu item from the BIOS setup screen to enter the Security Setup screen. Users can select any of the items in the left frame of the screen.




Feature	Description
Administrator Password	If ONLY the Administrator's password is set, it only limits access to Setup and is only asked for when entering Setup.
User Password	If ONLY the User's password is set, it serves as a power-on password and must be entered to boot or enter Setup. In Setup, the User will have Administrator rights.

Secure Boot



Feature	Options	Description
Secure Boot	Disabled Enabled	Secure Boot is activated when Platform Key (PK) is enrolled, System mode is User/Deployed, and CSM function is disabled.
Secure Boot Mode	Standard Custom	Customizable Secure Boot mode: In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication.


Key Management



Feature	Options	Description
Factory Key Provision	Disabled Enabled	Provision factory default keys on next re-boot only when System in Setup Mode.
Restore Factory Keys	None	Force System to User Mode. Configure NVRAM to contain OEM-defined factory default Secure Boot keys.
Enroll Efi Image	None	Allows the image to run in Secure Boot mode. Enroll SHA 256 hash of the binary into Authorized Signature Database (db)

Boot Menu

Select the Boot menu item from the BIOS setup screen to enter the Boot Setup screen. Users can select any of the items in the left frame of the screen.




Feature	Options	Description
Setup Prompt Timeout	5	The number of seconds to wait for setup activation key. 65535 means indefinite waiting
Bootup NumLock State	ON OFF	Select the keyboard NumLock state

- Choose boot priority from boot option group.
- Choose specifies boot device priority sequence from available Group device.


Save and Exit Menu

Select the Save and Exit menu item from the BIOS setup screen to enter the Save and Exit Setup screen. Users can select any of the items in the left frame of the screen.




■ Save Changes and Rest

When Users have completed the system configuration changes, select this option to save the changes and exit from BIOS Setup in order for the new system configuration parameters to take effect. The following window will appear after selecting the **"Save Changes and Exit"** option is selected. Select **"Yes"** to Save Changes and Exit Setup.




■ Discard Changes and Exit

Select this option to quit Setup without saving any modifications to the system configuration. The following window will appear after the **"Discard Changes and Exit"** option is selected. Select **"Yes"** to Discard changes and Exit Setup.



■ Restore Defaults


Restore default values for all setup options. Select **“Yes”** to load Optimized defaults.



Note: The items under Boot Override may not have the same image. It would depend on the devices connected to the system.

APPENDIX A: LED INDICATOR EXPLANATIONS

► Power / Status / Storage / M.2 / mPCIe LED



LED	COLOR	LED ACTION	DESCRIPTION
Power	Green	Steady	System is powered ON
	OFF	N/A	System is powered OFF
Status	Green	Steady	System is Active
	Red	Steady	System Error
	OFF	N/A	System is powered OFF
	Note: Status bi-color LED controlled by GPIO		
Storage	Yellow	Blinking	Storage (SATA/NVME) Active
	OFF	N/A	No Data Access
M.2	LED behavior will be determined by the inserted module card (optional)		
mPCIe	LED behavior will be determined by the inserted module card (optional)		

APPENDIX B: TERMS AND CONDITIONS

Warranty Policy

1. All products are under warranty against defects in materials and workmanship for a period of one year from the date of purchase.
2. The buyer will bear the return freight charges for goods returned for repair within the warranty period; whereas the manufacturer will bear the after-service freight charges for goods returned to the user.
3. The buyer will pay for repair (for replaced components plus service time) and transportation charges (both ways) for items after the expiration of the warranty period.
4. If the RMA Service Request Form does not meet the stated requirement as listed on "RMA Service, "RMA goods will be returned at customer's expense.
5. The following conditions are excluded from this warranty:
 - ▶ Improper or inadequate maintenance by the customer
 - ▶ Unauthorized modification, misuse, or reversed engineering of the product
 - ▶ Operation outside of the environmental specifications for the product.

RMA Service

Requesting an RMA#

1. To obtain an RMA number, simply fill out and fax the "RMA Request Form" to your supplier.
2. The customer is required to fill out the problem code as listed. If your problem is not among the codes listed, please write the symptom description in the remarks box.
3. Ship the defective unit(s) on freight prepaid terms. Use the original packing materials when possible.
4. Mark the RMA# clearly on the box.



Note: Customer is responsible for shipping damage(s) resulting from inadequate/loose packing of the defective unit(s). All RMA# are valid for 30 days only; RMA goods received after the effective RMA# period will be rejected.

RMA Service Request Form

When requesting RMA service, please fill out the following form. Without this form enclosed, your RMA cannot be processed.

RMA No:		Reasons to Return: ☐ Repair(Please include failure details)	
		☐ Testing Purpose	
Company:		Contact Person:	
Phone No.		Purchased Date:	
Fax No.:		Applied Date:	
Return Shipping Address: _____			
Shipping by: ☐ Air Freight ☐ Sea ☐ Express _____			
☐ Others: _____			
Item	Model Name	Serial Number	Configuration

Item	Problem Code	Failure Status

***Problem Code:**

01: D.O.A. 02: Second Time R.M.A. 03: CMOS Data Lost 04: FDC Fail 05: HDC Fail 06: Bad Slot	07: BIOS Problem 08: Keyboard Controller Fail 09: Cache RMA Problem 10: Memory Socket Bad 11: Hang Up Software 12: Out Look Damage	13: SCSI 14: LPT Port 15: PS2 16: LAN 17: COM Port 18: Watchdog Timer	19: DIO 20: Buzzer 21: Shut Down 22: Panel Fail 23: CRT Fail 24: Others (Pls specify)
--	---	--	--

Request Party

Confirmed By Supplier

Authorized Signature / Date

Authorized Signature / Date